

---

<b>Safety notice</b> .....		<b>section A</b>
<b>General information</b> .....		<b>section B</b>
<b>Parts list on board level</b> .....		<b>section C</b>
<b>Service sheets</b> .....		
<b>Transmitter (Internal control unit)</b> .....	<b>R791672</b> .....	<b>section D</b>
<b>Transmitter (Infra Red control unit)</b> .....	<b>R791664</b> .....	<b>section D</b>
<b>RGB input + switch</b> .....	<b>R7617481</b> .....	<b>section E</b>
<b>RGB Analog Auto Sync input</b> .....	<b>R7621055</b> .....	<b>section F</b>
<b>QUAD decoder+RGB Gain control</b> .....	<b>R7621745</b> .....	<b>section G</b>
Sub unit .....	<b>R762174S</b> .....	<b>section G</b>
<b>R /G /B output</b> .....	<b>R7621735</b> .....	<b>section H</b>
<b>CRT unit RED (Socket)</b> .....	<b>R7625202 (762508)</b> .....	<b>section I</b>
<b>CRT unit GREEN (Socket)</b> .....	<b>R7625205 (762508)</b> .....	<b>section I</b>
<b>CRT unit BLUE (Socket)</b> .....	<b>R7625206 (762508)</b> .....	<b>section I</b>
<b>Controller (Asic)</b> .....	<b>R7625115</b> .....	<b>section J</b>
<b>Deflection Switching</b> .....	<b>R762509</b> .....	<b>section K</b>
<b>Sync. + Vert. defl.</b> .....	<b>R7622685</b> .....	<b>section I</b>
Sub unit .....	<b>R762268S</b> .....	<b>section I</b>
Orbiting .....	<b>R762268U</b> .....	<b>section I</b>
<b>Hor. defl.</b> .....	<b>R7622675</b> .....	<b>section M</b>
<b>Mag. Focus+Hor. Shift</b> .....	<b>R762503</b> .....	<b>section N</b>
Sub unit .....	<b>R762271S</b> .....	<b>section N</b>
<b>SM Power Supply 2 +G2</b> .....	<b>R762506</b> .....	<b>section O</b>
Focus voltage stabilizer .....	<b>R762120S</b> .....	<b>section O</b>
<b>Convergences (driver)</b> .....	<b>R762518</b> .....	<b>section P</b>
<b>Convergences (output)</b> .....	<b>R762513</b> .....	<b>section Q</b>
Fan (convergence) .....	<b>R762523</b> .....	<b>section Q</b>
<b>Dynamic Astigmatism</b> .....	<b>R762514</b> .....	<b>section R</b>
<b>SM Power supply</b> .....	<b>R7621705</b> .....	<b>section S</b>
Sub unit .....	<b>R7621705S</b> .....	<b>section P</b>
<b>Power input</b> .....	<b>R762507</b> .....	<b>section T</b>
<b>EHT</b> .....	<b>R7617427</b> .....	<b>section U</b>
<b>Frame</b> .....	<b>R762501</b> .....	<b>section V</b>
<b>IR receiver module</b> .....	<b>R761781</b> .....	<b>section W</b>
<b>RS232</b> .....	<b>R762510</b> .....	<b>section X</b>
<b>Service Information</b> .....		
<b>Use of the service kit</b> .....	<b>R9827600</b> .....	<b>section Y</b>
<b>Replacement of a picture tube</b> .....		<b>section Z</b>
<b>Failure - I<sup>2</sup>C error</b> .....		<b>section A</b>
<b>Option modules</b> .....		
<b>IR remote receiver 800</b> .....	<b>R9827515</b> .....	<b>section B</b>
<b>Contrast modulation/Soft edge</b> .....	<b>R761876</b> .....	<b>section C</b>
<b>Soft edge</b> .....	<b>R761876S</b> .....	<b>section D</b>
<b>IBCL link</b> .....	<b>R9827861</b> .....	<b>section E</b>

---