


# VPH-1271Q

## RM-1271

# SERVICE MANUAL

*US Model*  
*Canadian Model*

Chassis No. SCC-D27B-A



**SuperData EX**

**Note:** The service manual for RM-1271 has been issued separately.

### MODELS OF THE SAME SERIES

|           |  |
|-----------|--|
| VPH-1271Q |  |
| VPH-1251Q |  |
|           |  |

### SPECIFICATIONS

#### Optical

|                               |  |
|-------------------------------|--|
| <b>Projection system</b>      | 3 picture tubes, 3 lenses, Horizontal inline system  |
| <b>Picture tube</b>           | 7-inch new high-brightness monochrome tubes, with coolant sealed   |
| <b>Projection lens</b>        | HACC (High-resolution Aspherical and Color Corrected) lenses<br>F 1.12/140mm   |
| <b>Projected picture size</b> | Factory-adjusted to 120 inches measured diagonally<br>70-300 inches measured diagonally adjustable by changing the parts |
| <b>Light output</b>           | 650 lm (white peak)<br>200 lm (all white)  |

#### General

|                     |  |
|---------------------|--|
| <b>Color system</b> | PAL, SECAM, NTSC and NTSC <sup>4.43</sup> systems, switched automatically            |
| <b>Resolution</b>   | 700 TV lines (VIDEO input)<br>1280x1024 pixels<br>(RGB input at fr: 64kHz, fv: 60Hz) |

#### RGB inputs

Horizontal frequency  
15kHz-85kHz

#### Test signal

Vertical frequency 38Hz-150Hz  
Cross-hair test pattern generator is incorporated.

#### Speaker Input

4x8cm (1 5/8x3 1/4 inches), 3W  
VIDEO IN

Y/C: 4-pin mini DIN connector  
Y (luminance) signal:  
1 Vp-p ±2dB, sync negative, 75 ohms terminated  
C (chrominance) signal:  
burst 0.286 Vp-p ±2dB, 75 ohms terminated (NTSC)  
0.3 Vp-p ±2dB, 75 ohms terminated (PAL)

— continued on next page —



**MULTISCAN PROJECTOR**  
**SONY** (H)

VIDEO: BNC connector  
Composite video input,  
1 Vp-p  $\pm 2$ dB, sync  
negative, 75 ohms  
terminated.

AUDIO IN  
phono jack  
500 m Vrms, Impedance: more  
than 47 k ohms

RGB input  
R: BNC connector  
Red input, 0.7 Vp-p  $\pm 2$ dB,  
75 ohms terminated, positive  
G/G SYNC: BNC connector  
Green input, 0.7Vp-p  $\pm 2$ dB,  
75 ohms terminated, positive  
Green with sync input,  
1Vp-p  $\pm 2$ dB, 75 ohms  
terminated, positive

B: BNC connector  
Blue input, 0.7Vp-p  $\pm 2$ dB,  
75 ohms terminated, positive

SYNC/HD: BNC connector  
Composite sync input,  
0.3–8Vp-p, high impedance,  
positive/negative  
Horizontal sync input,  
0.3–8Vp-p, high impedance,  
positive/negative

VD: BNC connector  
Vertical sync input, 0.3–8Vp-p,  
high impedance,  
positive/negative  
Width: wider than horizontal  
period (1H)

AUDIO IN L(MONO)/R: phone  
jacks

REMOTE 1 connector: 14-pin  
(see "Signal assignment")

REMOTE 2 connector: 9-pin  
(see "Signal assignment")

CONTROL S IN: minijack, 5Vp-p

VIDEO OUT: BNC connector  
Composite video output,  
1Vp-p  $\pm 2$ dB, impedance  
75 ohms, output video signal  
from the VIDEO IN connector

CONTROL S OUT: minijack,  
5Vp-p

**Outputs**

**Power requirements** 120 V AC, 50/60Hz

**Power consumption** VPH-1271Q: 450W

**Operating temperature**  $-10^{\circ}\text{C}$   $\rightarrow$   $+40^{\circ}\text{C}$   
(humidity: 10%  $-$  90%)

**Storage temperature**  $-20^{\circ}\text{C}$   $\rightarrow$   $+60^{\circ}\text{C}$   
(humidity: 10%  $-$  90%)

**Dimensions** Approx. 620x355x817mm (w/h/d)  
(24 1/2x14x32 1/4 inches)

**Weight** VPH-1271Q: 65kg (143 lb 5oz)

**Accessories supplied** Remote Commander RM-1271 (1)  
with 3 R6 (AA) batteries  
Remote Commander cable (1)  
AC power cord (1)  
Washer for optical axis adjustment  
(12 each for 4 sorts of thickness)  
CRT spacers (1set each for the size  
S and L))  
Spacer for rear projection  
(1 set each for the angles of optical  
axis  $0^{\circ}$  and  $2^{\circ}$ )

**Accessories (not supplied)**

**Signal interface switcher**  
PC-1271

**Projector suspension support**

PSS-1270, PSS-10  
VPS-100F1 (100" flat)  
VPS-120F (120" flat)  
VPS-72HG1 (72" curved)  
VPS-100HG1 (100" curved)  
VPS-700R (70" rear projection)


**CCQ BRS cables**  
**Interface board**

IFB-11 (5BNC, Analogue)  
IFB-20 (9-pin, Analogue)  
IFB-1000 (Video, Y/C)  
IFB-30 (9-pin, Digital)  
IFB-101

**Signal assignment**

REMOTE 1 connector (14-pin)


| Pin No. | Signal             |
|---------|--------------------|
| 1       | GND                |
| 2       | HD/Composite Sync  |
| 3       | SIRCS              |
| 4       | NC                 |
| 5       | GND(SIRCS)         |
| 6       | B/C                |
| 7       | GND(B/C)           |
| 8       | GND(G/Y)           |
| 9       | G/Y                |
| 10      | RGB/Video          |
| 11      | R/Composite Video  |
| 12      | Composite Video/YC |
| 13      | AUDIO              |
| 14      | VD                 |




REMOTE 2 connector (D-sub 9-pin)

| Pin No. | Signal          |
|---------|-----------------|
| 1       | Frame Ground    |
| 2       | Transit A       |
| 3       | Receive B       |
| 4       | Receive Common  |
| 5       | Spare           |
| 6       | Transmit Common |
| 7       | Transmit B      |
| 8       | Receive A       |
| 9       | Frame Ground    |

RS-422 format



Y/C connector (4-pin mini DIN)



**SAFETY-RELATED COMPONENT WARNING !!**

COMPONENTS IDENTIFIED BY SHADING AND MARK  ON THE SCHEMATIC DIAGRAMS, EXPLODED VIEWS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY. CIRCUIT ADJUSTMENTS THAT ARE CRITICAL TO SAFE OPERATION ARE IDENTIFIED IN THIS MANUAL. FOLLOW THESE PROCEDURES WHENEVER CRITICAL COMPONENTS ARE REPLACED OR IMPROPER OPERATION IS SUSPECTED.

**ATTENTION AUX COMPOSANTS RELATIFS À LA SÉCURITÉ!!**

LES COMPOSANTS IDENTIFIÉS PAR UNE TRAME ET PAR UNE MARQUE  SUR LES SCHÉMAS DE PRINCIPE, LES VUES EXPLOSÉES ET LES LISTES DE PIÈCES SONT D'UNE IMPORTANCE CRITIQUE POUR LA SÉCURITÉ DU FONCTIONNEMENT. NE LES REMPLACER QUE PAR DES COMPOSANTS SONY DONT LE NUMÉRO DE PIÈCE EST INDIQUÉ DANS LE PRÉSENT MANUEL OU DANS DES SUPPLÉMENTS PUBLIÉS PAR SONY. LES RÉGLAGES DE CIRCUIT DONT L'IMPOR- TANCE EST CRITIQUE POUR LA SÉCURITÉ DU FONCTIONNEMENT SONT IDENTIFIÉS DANS LE PRÉSENT MANUEL. SUIVRE CES PROCÉDURES LORS DE CHAQUE REMPLACEMENT DE COMPOSANTS CRITIQUES, OU LORSQU'UN MAUVAIS FONCTIONNE- MENT EST SUSPECTÉ.

## SAFETY CHECK-OUT (US Model only)

After correcting the original service problem, perform the following safety checks before releasing the set to the customer:

1. Check the area of your repair for unsoldered or poorly-soldered connections. Check the entire board surface for solder splashes and bridges.
2. Check the interboard wiring to ensure that no wires are "pinched" or contact high-wattage resistors.
3. Check that all control knobs, shields, covers, ground straps, and mounting hardware have been replaced. Be absolutely certain that you have replaced all the insulators.
4. Look for unauthorized replacement parts, particularly transistors, that were installed during a previous repair. Point them out to the customer and recommend their replacement.
5. Look for parts which, though functioning, show obvious signs of deterioration. Point them out to the customer and recommend their replacement.
6. Check the line cord for cracks and abrasion. Recommend the replacement of any such line cord to the customer.
7. Check the condition of the monopole antenna (if any).  
Make sure the end is not broken off, and has the plastic cap on it. Point out the danger of impalement on a broken antenna to the customer, and recommend the antenna's replacement.
8. Check the B+ and HV to see they are at the values specified. Make sure your instruments are accurate; be suspicious of your HV meter if sets always have low HV.
9. Check the antenna terminals, metal trim, "metallized" knobs, screws, and all other exposed metal parts for AC leakage. Check leakage as described below.

### LEAKAGE TEST

The AC leakage from any exposed metal part to earth ground and from all exposed metal parts to any exposed metal part having a return to chassis, must not exceed 0.5 mA (500 microampers). Leakage current can be measured by any one of three methods.

1. A commercial leakage tester, such as the Simpson 229 or RCA WT-540A. Follow the manufacturers' instructions to use these instruments.
2. A battery-operated AC milliammeter. The Data Precision 245 digital multimeter is suitable for this job.
3. Measuring the voltage drop across a resistor by means of a VOM or battery-operated AC voltmeter. The "limit" indication is 0.75 V, so analog meters must have an accurate low-voltage scale. The Simpson 250 and Sanwa SH-63Trd are examples of a passive VOM that is suitable. Nearly all battery operated digital multimeters that have a 2V AC range are suitable. (See Fig. A)

### HOW TO FIND A GOOD EARTH GROUND

A cold-water pipe is guaranteed earth ground; the cover-plate retaining screw on most AC outlet boxes is also at earth ground. If the retaining screw is to be used as your earth-ground, verify that it is at ground by measuring the resistance between it and a cold-water pipe with an ohmmeter. The reading should be zero ohms. If a cold-water pipe is not accessible, connect a 60-100 watts trouble light (not a neon lamp) between the hot side of the receptacle and the retaining screw. Try both slots, if necessary, to locate the hot side of the line, the lamp should light at normal brilliance if the screw is at ground potential. (See Fig. B)




Fig. A. Using an AC voltmeter to check AC leakage.





Fig. B. Checking for earth ground.

# TABLE OF CONTENTS

| <u>Section</u>                        | <u>Title</u>   | <u>Page</u> | <u>Section</u>                             | <u>Title</u>                                       | <u>Page</u> |
|---------------------------------------|--|-------------|--|--|-------------|
| <b>1. GENERAL</b>                     |  |             |  |  |             |
| 1-1.                                  | Location and Function of Controls .....                            | 6           | 4-1.                                       | Neck Assembly Installation .....                   | 207         |
| 1-2.                                  | Installation Diagrams .....  | 13          | 4-2.                                       | Display Inclination Adjustment by Main DY .....    | 207         |
| 1-3.                                  | Modifications of Parts .....                                       | 20          | 4-3.                                       | Sub-DY Adjustment .....                            | 207         |
| 1-4.                                  | When Installation does not Comply with Standard Measurements ..... | 31          | 4-4.                                       | GREEN Lens Focus Adjustment .....                  | 207         |
| 1-5.                                  | Notes on Screen .....  | 36          | 4-5.                                       | RED Lens Focus Adjustment .....                    | 208         |
| 1-6.                                  | Dynamic Picture Setting .....                                      | 39          | 4-6.                                       | BLUE Lens Focus Adjustment .....                   | 208         |
| 1-7.                                  | Connecting to the Projector Directly .....                         | 41          | 4-7.                                       | GREEN 2/4-Pole Adjustment .....                    | 208         |
| 1-8.                                  | Connecting when the Projector is Away from Other Equipment .....   | 44          | 4-8.                                       | RED 2/4-Pole Adjustment .....                      | 209         |
| 1-9.                                  | Connecting More than Four Input Sources .....                      | 46          | 4-9.                                       | BLUE 2/4-Pole Adjustment .....                     | 209         |
| 1-10.                                 | Before Starting Adjustment .....                                   | 49          | 4-10.                                      | GREEN Electric Focus Adjustment .....              | 209         |
| 1-11.                                 | Remote Control Operation .....                                     | 50          | 4-11.                                      | RED Electric Focus Adjustment .....                | 209         |
| 1-12.                                 | Projecting .....   | 54          | 4-12.                                      | BLUE Electric Focus Adjustment .....               | 209         |
| 1-13.                                 | Centering Adjustment .....   | 63          | 4-13.                                      | Registration Adjustment .....                      | 210         |
| 1-14.                                 | Adjustment Displays and Test Patterns .....                        | 65          | 4-14.                                      | White Balance Adjustment .....                     | 211         |
| 1-15.                                 | Adjustment Procedures .....  | 67          | 4-15.                                      | Y Board, IC4 (EEPROM) Replacement .....            | 213         |
| 1-16.                                 | Lens Focus Adjustment .....  | 68          | <b>5. SAFETY RELATED ADJUSTMENTS .....</b> |  |             |
| 1-17.                                 | Registration Adjustment .....                                      | 73          | <b>6. CIRCUIT ADJUSTMENTS</b>              |  |             |
| 1-18.                                 | Fine Adjustment of Each Input signal .....                         | 97          | 6-1.                                       | BA Board Adjustment .....                          | 219         |
| 1-19.                                 | Data Reset .....   | 103         | 6-2.                                       | E Board Adjustment .....                           | 221         |
| 1-20.                                 | To Activate the Protection on the Remote Commander .....           | 105         | 6-3.                                       | DA Board Adjustment .....                          | 221         |
| 1-21.                                 | Picture Adjustment .....   | 106         | <b>7. DIAGRAMS</b>                         |  |             |
| 1-22.                                 | Various Settings .....   | 107         | 7-1.                                       | Circuit Boards Location .....                      | 223         |
| 1-23.                                 | List of the Messages .....   | 108         | 7-2.                                       | Quick Reference .....                              | 224         |
| 1-24.                                 | List of Washers Used for Non-standard Installation .....           | 112         | 7-3.                                       | Block Diagrams .....                               | 225         |
| 1-25.                                 | Projection Distance by Angle of Optical Axis .....                 | 115         | 7-4.                                       | Schematic Diagrams and Printed Wiring Boards ..... | 239         |
| <b>2. DISASSEMBLY</b>                 |  |             |  |  |             |
| 2-1.                                  | Cabinet and Lens Removal .....                                     | 117         |  | Frame Schematic Diagram .....                      | 240         |
| 2-2.                                  | Picture Tube Removal .....   | 117         |  | BA Board .....                                     | 245         |
| 2-3.                                  | Power Block Removal (PA, K and NB Boards) .....                    | 118         |  | BB Board .....                                     | 260         |
| 2-4.                                  | High-Voltage Block Assembly Removal .....                          | 118         |  | BC, L and KA Boards .....                          | 270         |
| 2-5.                                  | Interface Unit, BA, BC and BB Boards Removal .....                 | 119         |  | CA (B) Board .....                                 | 275         |
| 2-6.                                  | CFA, CFB, CA (RG) and CA (B) Boards Removal .....                  | 120         |  | BM and QM Boards .....                             | 280         |
| 2-7.                                  | Y, DA, DB, DM, DD and DE Boards Removal .....                      | 121         |  | CA (RG) Board .....                                | 290         |
| 2-8.                                  | M1, M2 and M3A Boards Removal .....                                | 122         |  | CBR, CBG and CBB Boards .....                      | 299         |
| 2-9.                                  | Attachment Direction of the DC Fan .....                           | 123         |  | CFA, CFB, NA and NB Boards .....                   | 303         |
| <b>3. CIRCUIT DESCRIPTIONS</b>        |  |             |  |  |             |
| 3-1.                                  | Circuit Operation of BA Board .....                                | 125         |  | DA Board .....                                     | 307         |
| 3-2.                                  | Circuit Operation of BB Board .....                                | 129         |  | Y Board .....                                      | 319         |
| 3-3.                                  | Circuit Operation of CA (RG) and CA (B) Boards .....               | 133         |  | DB Board .....                                     | 333         |
| 3-4.                                  | Circuit Operation of DA Board .....                                | 140         |  | DC Board .....                                     | 342         |
| 3-5.                                  | Circuit Operation of DB Board .....                                | 149         |  | DM Board .....                                     | 352         |
| 3-6.                                  | Circuit Operation of DD Board .....                                | 151         |  | DD Board .....                                     | 359         |
| 3-7.                                  | Circuit Operation of DE Board .....                                | 153         |  | DE Board .....                                     | 365         |
| 3-8.                                  | Circuit Operation of DC Board .....                                | 157         |  | E Board .....                                      | 374         |
| 3-9.                                  | Circuit Operation of E Board .....                                 | 159         |  | PA, PB and K Boards .....                          | 384         |
| 3-10.                                 | Circuit Operation of PA Board .....                                | 173         |  | RC, RCA, RCB, RCC and RCD Boards .....             | 392         |
| 3-11.                                 | Circuit Operation of K Board .....                                 | 182         |  | M1, M3A and C1 Boards .....                        | 398         |
| 3-12.                                 | Circuit Operation of Y Board .....                                 | 183         |  | M2 and C2 Boards .....                             | 404         |
| 3-13.                                 | Circuit Operation of KA Board .....                                | 197         | 7-5.                                       | Semiconductors .....                               | 410         |
| 3-14.                                 | Circuit Operation of BC Board .....                                | 197         | <b>8. EXPLODED VIEWS</b>                   |  |             |
| 3-15.                                 | Circuit Operation of L Board .....                                 | 199         | 8-1.                                       | Lens .....   | 413         |
| 3-16.                                 | Self-diagnostics (Troubleshooting) .....                           | 199         | 8-2.                                       | ED Block .....                                     | 414         |
| 3-17.                                 | SOPS-1036 .....  | 205         | 8-3.                                       | C Shield Block .....                               | 415         |
|                                       |  |             | 8-4.                                       | Base 1 .....                                       | 416         |
|                                       |  |             |  | Base 2 .....                                       | 417         |
|                                       |  |             | 8-5.                                       | Power Block .....                                  | 418         |
| <b>9. ELECTRICAL PARTS LIST .....</b> |  |             |  |  |             |
|                                       |  |             |  |  | 419         |

# SECTION 1 GENERAL

## 1-1. LOCATION AND FUNCTION OF CONTROLS




- 1 Control panel**  
There are the control keys inside the panel.
- 2 Red lens**
- 3 Green lens**
- 4 Blue lens**

- 5 Speaker**
- 6 Front remote control detector**
- 7 MAIN POWER switch (  ON/  OFF)**  
Press to turn on and off the main power.
- 8 AC IN socket**  
Connect the supplied AC power cord (mains lead).


**Bottom**

**Handle**

Used for carrying the projector. Pull out to use.




**Putting the handle away**



**How to use the adjusters**

The horizontal tilt of the projector can be adjusted using the adjusters.



**1 While lifting the projector using a handle, turn the screw to the left.**

Adjuster comes out.

By using the philips-head screwdriver, you can turn the screw without lifting the projector.

**2 Adjust the height.**

If it is too high, turn the screw to the right to lower the projector.

If it is too low, lift the projector again and turn the screw to the left to heighten the projector.


**To retract the adjusters**

Tighten the screw by turning to the right.

When the screw is tightened completely, the adjusters are locked and put away.


Retract the adjusters when carrying the projector.

Rear



- 1 **Rear remote control detector**
- 2 **POWER indicator**  
Green indicator is on when the power is turned on.
- 3 **STANDBY indicator**  
When the MAIN POWER switch is on, the red light indicating standby will be on. When the red light is on, the projector can be controlled with the Remote Commander.  
**Note**  
When the MAIN POWER switch is turned off, there will be a slight delay before the red light goes off.
- 4 **REMOTE 1 connector (14-pin)**  
Connect to the REMOTE 1 connector of the PC-1271 switcher (not supplied).
- 5 **REMOTE 2 connector (9-pin)**  
Connect RS-422 interface for interactive communication with the external equipment. Take off the red cap before use.
- 6 **CONTROL S IN/OUT connectors**  
Connect to the CONTROL S connectors of other Sony equipment.  
**CONTROL S IN:** Connect to the CONTROL S OUT connector of the supplied Remote Commander to use as a wired Commander.
- 7 **VIDEO IN connectors**  
**Y/C (4-pin):** Connect to the Y/C output of a VTR.  
**VIDEO (BNC type):** Connect to the video output of video equipment.  
**Note**  
The VIDEO connector is disconnected automatically when a cable is connected to the Y/C connector.
- 8 **AUDIO IN jack (phono)**  
Connect to the audio output of video equipment.
- 9 **VIDEO OUT connector (BNC type)**  
Connect to the video input of a color monitor. The signal input from the Y/C connector is not output from this connector.
- 10 **Indicator**  
Lights when INPUT A mode is selected.  
The optional interface board is also equipped with this indicator which lights when INPUT B mode is selected.
- 11 **RGB IN connectors (BNC type)**  
R, G/G SYNC, B, SYNC/HD, VD connectors:  
Connect to the RGB outputs of a computer or a video camera.
- 12 **AUDIO L/R IN jacks (phono)**  
Connect to the audio output of a computer or a video camera connected to the RGB IN connectors. For stereo equipment, use the AUDIO L and R IN jacks. For monaural equipment, use the AUDIO L IN jack only.  
**Note**  
The projector is monaural so that sound will not be reproduced in stereo.

## Remote Commander RM-1271




- 1 LIGHT button**  
Press to light key indicators.  
If the keys are not operated within about 30 seconds, the light automatically goes out.
- 2 Transmission indicator**  
The light goes on each time a key is pressed. When the indicator does not light, replace the batteries.
- 3 MEMORY key**  
Press to store various adjustment data into memory.
- 4 STATUS ON/OFF key**  
Press **OFF** to eliminate the on-screen display.  
Press **ON** to restore the on-screen display.  
**Note:** The PAGE display appears even when the **OFF** key is pressed.
- 5 SECAM key**  
When SECAM signal is input to the projector and you cannot get normal color, press this key. Press again to switch over to the other standard system sources, NTSC or PAL.
- 6 C.B. (clear blue) key**  
Press to make the blue color clear in RGB mode. Press again to restore the normal condition.
- 7 RGB SIZE key**  
Press to adjust the size of the picture for the video and RGB signal inputs.  
Press this key to enter the size adjustment mode. The size adjustment is performed using the four arrow keys.  
▶ ..... to reduce the horizontal size  
◀ ..... to expand the horizontal size  
▲ ..... to expand the vertical size  
▼ ..... to reduce the vertical size
- 8 RGB SHIFT key**  
Press to adjust the shift of the picture for the RGB signal input.  
Press this key to enter the shift adjustment mode. The shift adjustment of the picture is performed using the four arrow keys. The picture shifts according to the direction of the arrow.  
**Note**  
This key does not function with the video signal input.
- 9 CENT R/B keys**  
Press to enter the centering adjustment mode of the red and blue.  
**CENT R:** Press to enter the red centering adjustment mode.  
**CENT B:** Press to enter the blue centering adjustment mode.  
Centering adjustments are performed using the four arrow keys.  
To return to the normal display, press the MEMORY key.


- 10 Arrow keys**  
The keys are used for various adjustment functions.
- 11 PJ MUTE keys**  
**PIC:** Press to cut off the picture. To restore the picture, press it again or CONTR +.  
**AUDIO:** Press to cut off the sound. To restore the sound, press it again or VOL +.
- 12 POWER ON/OFF keys**  
Press to turn on and off the projector.
- 13 VOL (volume) +/- keys**  
Press to adjust volume.  
+: to increase volume  
-: to decrease volume
- 14 PICTURE CONTROL keys**  
Press to adjust picture condition: hue, sharpness, brightness, color and contrast. Press RESET to restore the standard levels.
- 15 SWITCHER/INDEX keys**  
**When the SWITCHER/INDEX select switch is set to SWITCHER**  
When the PC-1271 switcher is connected, select the input from the switcher. The SECOND key is used when two switchers are connected. To select the input from the second switcher (when the switcher's SINGLE/REMOTE 2/SECOND switch is set to SECOND), press the number keys after pressing SECOND. Number key 9 does not operate.  
**When the SWITCHER/INDEX select switch is set to INDEX**  
These keys function when the IFB-101 interface board (not supplied) is attached and multiple projectors are connected. For details, refer to the instructions manual of the IFB-101.
- 16 INPUT SELECT keys**  
Press to select the input signal.  
**VIDEO:** to select the signal input from the VIDEO IN (Y/C or VIDEO) connectors  
**A:** to select the signal input from the RGB IN connectors  
**B:** to select the signal input from the connectors of B section (when the optional interface board is attached)
- 17 PAGE key**  
Press to display and switch the following five on-screen displays. (On PAGE 1, 2, 3 and 5, adjustment can also be done.)  
**PAGE 1:** Displays STATUS ON/OFF, PIC MUTE ON/OFF, AUDIO MUTE ON/OFF, CLEAR BLUE ON/OFF and SECAM ON/OFF.  
**PAGE 2:** Displays the picture conditions; contrast, color, brightness, sharpness and hue, and volume level.  
**PAGE 3:** Displays the color temperature level, clamp setting and vertical shift range.  
**PAGE 4:** Displays the input signal conditions; fH, fV H/ C-sync, V-sync, Sync on Green and input signal and registration memory block assignment.  
**PAGE 5:** Displays the current use time of each cathode-ray tube (CRT) and the baud rate setting for communicating via the RS-422.
- 18 SWITCHER/INDEX select switch**  
Selects the SWITCHER/INDEX key function.  
When using as the switcher input selector, set to SWITCHER.  
When attaching the IFB-101 interface board (not supplied) on the control panel of the projector and controlling multiple projectors, set to INDEX.
- 19 ENTER key**  
This key functions when the IFB-101 interface board (not supplied) is attached and multiple projectors are connected. For details, refer to the instructions manual of the IFB-101.
- 20 CONTROL S OUT connector**  
Connect the supplied remote control cable to this connector and to the CONTROL S IN connector of the projector for wired Commander application.

**Battery installation**


**1** Push to open the lid.



**2** Install three R6 (AA) batteries with the correct polarity.




**3** Replace the lid.



- If the projector does not operate properly, the batteries might be worn out. Replace all three of them with new batteries.
- The life of the batteries depends on frequency of usage and how often you use the LIGHT button. If they wear out quickly, replace them with new alkaline batteries.
- To avoid damage from possible battery leakage, remove the batteries when the Commander will not be used for a long time.

- Be sure that there are no obstructions between the Commander and the unit.
- Operable range is limited. The shorter the distance between the Commander and the projector, the wider the angle within which the Commander can control the projector.

**To connect the Remote Commander to the projector**




**Note**

When the above connection is made, the remote control detector of the projector does not function. For wireless operation, be sure to disconnect both plugs from the projector and the Commander.

1-2. INSTALLATION DIAGRAMS

**Floor Installation Using Front Projection Flat Screen**

Be sure that the projector is parallel to the floor.



| Screen size (inches) | Length mm (inches) |                |             |                 |                 |              | Angle (°) |
|----------------------|--------------------|----------------|-------------|-----------------|-----------------|--------------|-----------|
|                      | A                  | B              | C           | D               | E               | F            |           |
| 70                   | 1,067 (42 1/8)     | 743 (29 3/8)   |             | 2,056 (81)      | 1,995 (78 5/8)  | 297 (11 3/4) | 14.0      |
| 80                   | 1,219 (48 1/8)     | 908 (35 3/4)   |             | 2,326 (91 3/4)  | 2,257 (89)      | 296 (11 3/4) | 14.0      |
| 100*                 | 1,524 (60)         | 960 (37 7/8)   | 24 (31/32)  | 2,859 (112 3/4) | 2,769 (109 1/4) | 293 (11 5/8) | 14.5      |
| 120**                | 1,829 (72 1/4)     | 1,091 (43)     | 35 (1 7/16) | 3,386 (133)     | 3,279 (129 3/8) | 291 (11 1/2) | 14.5      |
| 150                  | 2,286 (90 1/4)     | 1,319 (52)     |             | 4,204 (165 3/4) | 4,065 (160 1/8) | 288 (11 3/8) | 14.8      |
| 180                  | 2,743 (108)        | 1,517 (59 3/4) |             | 4,981 (147 3/8) | 4,816 (190)     | 286 (11 3/8) | 14.8      |
| 200                  | 3,048 (120)        | 1,653 (65 1/8) |             | 5,516 (163 1/8) | 5,334 (210)     | 285 (11 1/4) | 14.8      |
| 250                  | 3,810 (150 3/8)    | 1,997 (78 3/4) |             | 6,862 (220 5/8) | 6,635 (261 1/4) | 284 (11 1/4) | 14.8      |
| 300                  | 4,572 (180)        | 2,343 (92 3/8) |             | 8,208 (323 1/4) | 7,935 (312 1/2) | 283 (11 1/4) | 14.8      |


\*Sony VPS-100F1

\*\*Sony VPS-120F

**Necessary modifications of parts**

- Spacer change (not necessary for use of the 100- and 120-inch screens)

## Floor Installation Using Front Projection Curved Screen



| Screen size (inches) | Length mm (inches) |                   |                |                    |                 |                |                 | Angle (°) |      |     |
|----------------------|--------------------|-------------------|----------------|--------------------|-----------------|----------------|-----------------|-----------|------|-----|
|                      | A                  | B                 | C              | D                  | E               | F              | G               | a         | b    | d   |
| 72*                  | 1,125<br>(44 3/8)  | 1,886<br>(74 1/2) | 184<br>(7 1/4) | 2,180<br>(86)      | 739<br>(29 1/8) | 1,854<br>(73)  | 297<br>(11 3/4) | 31.7      | 18.1 | 4.5 |
| 100**                | 1,600<br>(63)      | 2,107<br>(83)     | 303<br>(12)    | 3,002<br>(118 1/4) | 545<br>(21 1/2) | 2,564<br>(101) | 293<br>(11 5/8) | 31.4      | 17.4 | 3.4 |

\*Sony VPS-72HG1


\*\*Sony VPS-100HG1

### Necessary modifications of parts

- Spacer change (only for use of the 72-inch screen)

## Ceiling Installation Using Front Projection Flat Screen

Be sure that the projector is parallel to the ceiling.



| Screen size (inches) | Length mm (inches) |                |             |                 |                 |              | Angle (°) |
|----------------------|--------------------|----------------|-------------|-----------------|-----------------|--------------|-----------|
|                      | A                  | B              | C           | D               | E               | F            | a         |
| 70                   | 1,067 (42 1/8)     | 923 (36 3/8)   |             | 2,056 (81)      | 1,995 (78 5/8)  | 323 (12 3/4) | 14.0      |
| 80                   | 1,219 (48 1/8)     | 988 (39)       |             | 2,326 (91 3/4)  | 2,257 (89)      | 320 (12 5/8) | 14.0      |
| 100*                 | 1,524 (60)         | 1,140 (45)     | 24 (31/32)  | 2,859 (112 3/4) | 2,769 (109 1/4) | 318 (12 5/8) | 14.5      |
| 120**                | 1,829 (72 1/4)     | 1,271 (50 1/8) | 35 (1 7/16) | 3,386 (133)     | 3,279 (129 3/8) | 316 (12 1/2) | 14.5      |
| 150                  | 2,286 (90 1/4)     | 1,499 (59 1/8) |             | 4,204 (165 3/4) | 4,065 (160 1/8) | 314 (12 3/8) | 14.8      |
| 180                  | 2,743 (108)        | 1,697 (67)     |             | 4,981 (147 3/8) | 4,816 (190)     | 312 (12 3/8) | 14.8      |
| 200                  | 3,048 (120)        | 1,833 (72 1/4) |             | 5,516 (163 1/8) | 5,334 (210)     | 310 (12 1/4) | 14.8      |
| 250                  | 3,810 (150 3/8)    | 2,177 (85 3/4) |             | 6,862 (220 5/8) | 6,635 (261 1/4) | 308 (12 1/4) | 14.8      |
| 300                  | 4,572 (180)        | 2,523 (99 3/8) |             | 8,208 (323 1/4) | 7,935 (312 1/2) | 306 (12 1/8) | 14.8      |


\*Sony VPS-100F1

\*\*Sony VPS-120F

### Necessary modifications of parts

- Spacer change (not necessary for use of 100- and 120-inch screens)
- Polarity change on the DC and E boards

## Ceiling Installation Using Front Projection Curved Screen



| Screen size (inches) | Length mm (inches) |                   |                 |                    |                   |                 |                 | Angle (°) |     |     |
|----------------------|--------------------|-------------------|-----------------|--------------------|-------------------|-----------------|-----------------|-----------|-----|-----|
|                      | A                  | B                 | C               | D                  | E                 | F               | G               | a         | b   | d   |
| 72*                  | 1,125<br>(44 3/8)  | 1,271<br>(50 1/8) | 185<br>(7 3/8)  | 2,180<br>(86)      | 2,025<br>(79 3/4) | 267<br>(10 5/8) | 464<br>(18 3/8) | 21.7      | 8.1 | 5.5 |
| 100**                | 1,600<br>(63)      | 1,639<br>(64 3/4) | 305<br>(12 1/8) | 3,002<br>(118 1/4) | 2,764<br>(109)    | 255<br>(10 1/8) | 467<br>(18 1/2) | 23.0      | 9.0 | 5.0 |

\*Sony VPS-72HG1


\*\*Sony VPS-100HG1

### Necessary modifications of parts

- Spacer change (only for use of the 72-inch screen)
- Polarity change on the DC and E boards

## When the Screen Size is Not Mentioned in the Tables

When using the front projection screen for both floor and ceiling installations, the installation measurements can be calculated as follows:



### When the screen size is between 70 and 85 inches

$$E \text{ (mm)} = 25.78 \times \text{Screen size} + 191$$

$$B \text{ (mm)} = \text{Value } E \text{ (mm)} \times 0.249 + 246$$

**Example:** 75-inch screen

$$E = 25.78 \times 75 + 191 = 2,125 \text{ mm}$$

$$B = 2,125 \times 0.249 + 246 = 775 \text{ mm}$$

### When the screen size is between 86 and 139 inches

$$E \text{ (mm)} = 25.78 \times \text{Screen size} + 191$$

$$B \text{ (mm)} = \text{Value } E \text{ (mm)} \times 0.258 + 246$$

### When the screen size is between 140 and 300 inches

$$E \text{ (mm)} = 25.78 \times \text{Screen size} + 191$$

$$B \text{ (mm)} = \text{Value } E \text{ (mm)} \times 0.264 + 246$$

## Floor Installation Using Rear Projection Flat Screen


### What Is the angle of optical axis?

The angle of optical axis is the angle between the horizontal line which is level with the center of the screen and the straight line from the center of the projector's green lens to the center of the screen. When a rear projection screen is used, you can get the brightest picture along the extension of the straight line between the center of the green lens and the center of the screen.

Therefore, the most suitable angle of optical axis (a) varies depending on the height of the screen and the line of your sight.

A standard rear projection installation is that wherein this angle is 0° or 2°.

### When the angle of optical axis is 0°




$a = 0^\circ$  ( $b = 13.4^\circ \pm 0.5^\circ$ )

| Screen size (inches) | Length mm (inches) |             |                 |                 |
|----------------------|--------------------|-------------|-----------------|-----------------|
|                      | A                  | B           | C               | D               |
| 70                   | 1,067 (42 1/8)     | 174 (6 7/8) | 2,384 (93 7/8)  | 2,037 (80 1/4)  |
| 80                   | 1,219 (48 1/8)     | 174 (6 7/8) | 2,659 (104 3/4) | 2,314 (91 1/8)  |
| 100                  | 1,524 (60)         | 174 (6 7/8) | 3,171 (124 7/8) | 2,829 (111 1/2) |
| 120                  | 1,829 (72 1/4)     | 174 (6 7/8) | 3,690 (145 3/8) | 3,351 (132)     |
| 150                  | 2,286 (90 1/4)     | 174 (6 7/8) | 4,480 (176 1/2) | 4,143 (163 1/4) |
| 180                  | 2,743 (108 1/4)    | 174 (6 7/8) | 5,265 (207 3/8) | 4,529 (194 1/8) |
| 200                  | 3,048 (120 3/8)    | 174 (6 7/8) | 5,791 (228 3/8) | 5,456 (214 7/8) |
| 250                  | 3,810 (150)        | 174 (6 7/8) | 7,120 (280 3/8) | 6,787 (267 1/4) |
| 300                  | 4,572 (180)        | 174 (6 7/8) | 8,449 (332 3/4) | 8,118 (319 3/4) |

### Necessary modifications of parts

- Spacer change (not necessary for the CRT spacers when using the 100- and 120-inch screens)
- Polarity change on the E board

**When the angle of optical axis is 2°**



$a = 2^\circ$  ( $b = 15.4^\circ \pm 0.5^\circ$ )

| Screen size (inches) | Length mm (inches) |                 |                 |                 |
|----------------------|--------------------|-----------------|-----------------|-----------------|
|                      | A                  | B               | C               | D               |
| 70                   | 1,067 (42 1/4)     | 91 (3 5/8)      | 2,388 (94 1/8)  | 2,035 (80 3/16) |
| 80                   | 1,219 (48 1/8)     | 80 (3 1/4)      | 2,685 (105 3/4) | 2,334 (92)      |
| 100                  | 1,524 (60)         | 63 (2 1/2)      | 3,174 (125)     | 2,826 (111 3/8) |
| 120                  | 1,829 (72 1/4)     | 45 (1 13/16)    | 3,692 (145 3/8) | 3,347 (131 7/8) |
| 150                  | 2,286 (90 1/4)     | 17 (11/16)      | 4,496 (177 1/8) | 4,153 (163 5/8) |
| 180                  | 2,743 (108 1/4)    | - 10 (- 13/32)  | 5,266 (207 3/8) | 4,924 (194)     |
| 200                  | 3,048 (120 3/8)    | - 28 (- 1 1/8)  | 5,791 (228 3/8) | 5,450 (214 5/8) |
| 250                  | 3,810 (150)        | - 75 (- 3)      | 7,118 (280 3/8) | 6,779 (267)     |
| 300                  | 4,572 (180)        | - 120 (- 4 3/4) | 8,447 (332 5/8) | 8,109 (319 3/8) |

**Necessary modifications of parts**


- Spacer change (not necessary for the CRT spacers when using the 100- and 120-inch screens)
- Polarity change on the E board

### 1-3. MODIFICATIONS OF PARTS


To modify certain parts in the projector, such as changing the spacers, open the hood after removing the top panel. You may keep the hood open by supporting it with the stay, or remove the hood while making modifications. It is also necessary to remove the power block and HV block depending on the modifications.

## Opening the Hood


- 1** Push the part marked "PUSH" on the control panel cover to open.  
(Do not use force to open.)



- 2** Loosen the two screws of the control panel and slide the top panel in the direction of the arrow. (The screws do not come out of the hole to prevent their getting lost.)




- 3** Open the top panel toward the lens section, and remove it.




To be continued


- 4** Press down the levers on both sides of the front panel to open toward you and remove the front panel.



- 5** Lift the front side of the hood upward.



- 6** Raise the stay to support the hood properly.



**Note**


You can remove the hood if necessary.

**To replace the hood, front panel and top panel**


- 1 Retract the stay properly in the stay lock.
- 2 Position the hood so that the two screws can be inserted into their locations on the control panel. Tighten the screws.
- 3 Replace the front panel and press it until both levers click.
- 4 Replace the top panel.

## Removing the Power Block and HV Block


- 1** Loosen the two screws at both sides of the power block.  
(The screws are retained in the hole, to prevent their getting lost.)




- 2** Pull the power block out toward you.



- 3** Loosen the two screws of the HV block. (The screws are retained in the hole, to prevent their getting lost.)



- 4** Pull the HV block out toward you.



### To replace the power block and HV block

- 1 Replace the HV block and tighten the two screws, making sure that the lead wire is not sagging.
- 2 Reinstall the power block. Make sure that it is pushed inside fully and then fasten the screws.

## Changing the CRT Spacers


The CRT spacers of the projector attached at the factory are for 86- to 139-inch front projection (or for 80- to 123-inch rear projection). For projection other than these screen sizes, the CRT spacers must be replaced.

The CRT spacers should be attached to the blue and red cathode-ray tubes only.

### How to change the CRT spacers

Use a box screwdriver 400 mm long with a diagonal measurement of 8 mm.

- 1** Remove the hood.
- 2** Remove the power block and HV block.
- 3** Loosen the four screws and remove the two CRT spacers that were attached at the factory for red and blue cathode-ray tubes.



**4** Confirm the necessary spacer size using the following table and attach the supplied CRT spacers to both the outside and inside of the red and blue cathode-ray tubes.

Attach the spacers with the "OUT" mark to the outside and the ones with the "IN" mark to the inside of the CRTs.

**Front projection**

|                      |         |          |           |
|----------------------|---------|----------|-----------|
| Screen size (inches) | 70 — 85 | 86 — 139 | 140 — 300 |
| Size mark            | S       | M        | L         |


**Rear projection**

|                      |         |          |           |
|----------------------|---------|----------|-----------|
| Screen size (inches) | 70 — 79 | 80 — 123 | 124 — 300 |
| Size mark            | S       | M        | L         |

**Note**

When the washers are to be inserted, see the table for front projection even in the case of rear projection.

CRT spacer



**5** Fasten all screws as before.


## Changing the Lens Spacers for Front Projection

The lens spacers attached at the factory are for 86- to 139-inch front projection. For projection other than these screen sizes, change the lens spacers.


**1** Remove the hood.

**2** Remove the power block and HV block.

**3** Loosen the four screws each of the red, green, and blue lenses. Make sure that the projections under the two upper screws are separated from the lens spacer.




**4** Separate the projection on the rear of the lens spacer from the hole mark on the lens support.




**5** Confirm which hole is to be used, using the following table.  
Align the screw with that hole to fix the lens spacer to the lens support.

| Lens  | Lens spacer | Screen size (Inches) |                                 |           |
|-------|-------------|----------------------|---------------------------------|-----------|
|       |             | 70 — 85              | 86 — 139                        | 140 — 300 |
| Red   | R FRONT     | S                    | M<br>(preset at<br>the factory) | L         |
| Green | G FRONT     |                      |                                 |           |
| Blue  | B FRONT     |                      |                                 |           |

③ Align the projection on the rear of the lens spacer with the hole mark on the lens support.



② Align the screw with the correct hole.



**6** Make sure that each lens spacer is firmly attached to the lens support and fasten the four screws for each lens.

**7** Reinstall the power block and HV block.

**8** Reinstall the hood, front panel and top panel.

**Note**

If it is difficult to change the lens spacer while the lens is attached, remove the lens.

## Changing the Lens Spacers for Rear Projection

### Screen sizes and the necessary spacers

Determine the necessary spacers and confirm the size to be used.

| Angle of optical axis | Lens  | Lens spacer | Screen size*         |          |           |
|-----------------------|-------|-------------|----------------------|----------|-----------|
|                       |       |             | 70 — 79              | 80 — 123 | 124 — 300 |
| 0°                    | Red   | R-0 REAR    | S                    | M        | L         |
|                       | Green | G-0 REAR    | Usable for all sizes |          |           |
|                       | Blue  | B-0 REAR    | S                    | M        | L         |
| 2°                    | Red   | R-2 REAR    | S                    | M        | L         |
|                       | Green | G-2 REAR    |                      |          |           |
|                       | Blue  | B-2 REAR    |                      |          |           |



\* Note that the screen size ranges differ from those of lens spacers for front projection.

#### Note

When the washers are to be inserted, see the table for front projection, even in the case of rear projection.

### How to change the lens spacers

- 1** Remove the hood.
- 2** Remove the power block and HV block.
- 3** Remove the lenses from the lens supports.  
Remove the four screws of each lens and pull the lens out toward you.





#### How to keep the separated lenses






Be sure to keep the lenses with the CRT side up. Treat the lenses carefully.

## 4 Remove each lens spacer.



## 5 See the table on page 27 to select the correct lens spacer from the supplied ones. Then, confirm the hole to be used and fix the lens spacer with the lens support, aligning that hole.

- R-0 · REAR : For red, angle of optical axis "0°"
- B-0 · REAR : For blue, angle of optical axis "0°"
- R-2 · REAR : For red, angle of optical axis "2°"
- B-2 · REAR : For blue, angle of optical axis "2°"
- G-2 · REAR : For green, angle of optical axis "2°"



③ Align the projection on the rear of the lens spacer with the hole mark on the lens support.

② Align the hole to be used with the screw hole on the lens support.

## 6 Reinstall the lenses. Make sure that each lens spacer is firmly attached to the lens support, then fasten the four screws for each lens.

## 7 Reinstall the power block and HV block.

## 8 Reinstall the hood, front panel and top panel.

## Changing the Polarity

This projector is preset at the factory for use in front projection when the projector is installed on the floor/desk. When the projector is installed on the ceiling or used in rear projection, the display will be shown as follows when the power is turned on. Change the polarity to reverse the display.




|          |  |
|----------|--|
| <b>A</b> | <p>The letters are backward.<br/>Change the connectors on the E board.</p> <div style="border: 1px solid black; padding: 5px; margin: 10px auto; width: fit-content;"> <p style="text-align: center;"><b>A-TUPNI</b></p> <p style="text-align: center;">For optimum performance, white screen will remain for 20min. For immediate use, push [PAGE] key.</p> </div>  |
| <b>B</b> | <p>The letters are upside down.<br/>Change the connectors on the DC board.</p> <div style="border: 1px solid black; padding: 5px; margin: 10px auto; width: fit-content;"> <p style="text-align: center;">push [PAGE] key. For immediate use, white screen will remain for 20min. For optimum performance, white screen will remain for 20min. For immediate use, push [PAGE] key.</p> <p style="text-align: right;"><b>A-TUPNI</b></p> </div> |
| <b>C</b> | <p>The letters are upside down and backward.<br/>Change the connectors on the DC and E boards.</p> <div style="border: 1px solid black; padding: 5px; margin: 10px auto; width: fit-content;"> <p style="text-align: center;">For optimum performance, white screen will remain for 20min. For immediate use, push [PAGE] key.</p> <p style="text-align: left;"><b>A-TUPNI</b></p> </div>  |

### How to change the polarity

**1** Turn off the power.

**2** Open the hood.




**3** Change the connectors.



**4** Make sure to insert the connectors firmly.

**Necessary polarity changes according to the installation methods**

Y: Necessary  
N: Not necessary


| Installation methods   | Change on DC board  | Change on E board | On-screen Display |
|--|---|-------------------|-------------------|
| Front projection, ceiling  | Y   | Y                 | C                 |
| Rear projection, floor   | N   | Y                 | A                 |
| Rear projection, ceiling   | Y   | N                 | B                 |
| <b>Rear projection using mirrors</b><br>Using a mirror<br> | N   | N                 | Correct picture   |
| Using a mirror<br>  | Y   | Y                 | C                 |
| Using two mirrors<br>                                     | N   | Y                 | A                 |
| <b>Others</b>  | Display the letters on the screen and determine which changes to be made. |                   |                   |

#### 1-4. WHEN INSTALLATION DOES NOT COMPLY WITH STANDARD MEASUREMENTS


If the projector cannot be installed using a standard installation method mentioned on pages 13 to 19, you cannot obtain the picture in focus no matter how you adjust the lens focus. In that case, insert the supplied washers between the lens and cathode-ray tube so that the lens can be focused.

### Variable Range of the Angle of Optical Axis in Rear Projection

This projector can be installed on the floor within an angle of optical axis  $2^\circ$  to  $-13^\circ$  as shown in the illustration.






When the projector is installed on the ceiling, the angle of optical axis must be within  $+3^\circ$  to  $+13^\circ$ .



If the angle is  $0^\circ$  or  $2^\circ$ , you need not insert the washers.

# Selecting the Washer

- 1** Use the installation plan to find the angle (a) on the straight line from the center of the screen to the center of the projector's green lens. When there is an angle (b) on a screen (which is not perpendicular) as shown in the illustrations, subtract this angle (b) from the angle (a) to find the angle of optical axis against the screen.



To be continued

**2** Use the “List of washers used for non-standard installation” to determine the washers (A) required in accordance with the corresponding angle and the screen size.

**Example: When the angle is 8° with a 120-inch screen**

The data given in the list is as follows.

|   |           |
|---|-----------|
| A | 0.4 + 0.4 |
| B | 65        |

( A: Washer thickness )  
( B: See page 112. )


In this case, install two 0.4-mm thick washers (supplied).

**Notes**

- Use the same washer for this angle in any installation method, including floor and ceiling installations. For example, use the same washer for 10° in both a floor installation with the angle of - 10° and a ceiling installation with the angle of + 10°.
- When you use a curved screen (or a screen with a large screen gain), determine the angle of the screen as first priority so that you can get the brightest picture. (Refer to the illustration with the curved screen in step 1 above.)
- If the angle of optical axis is changed, the projection distance also changes. Refer to the tables on pages 115 and 116 and remake your own installation plan by correcting the projection distance.

If you cannot get the optical axis using the installation plan, determine the washers to be used by the following procedure.

- 1** Measure the distance (E) from the screen to the center of the green lens.



- 2** Measure the difference in height (B') between the center of the screen and the center of the green lens.

- 3** Divide B' by E.


- 4** Use the "List of washers used for non-standard installation" and determine the washers required in accordance with the corresponding value given by step 3 and the screen size.

## How to insert the washers



**1** Open the hood.

**2** Remove the power block and HV block.

**3** Remove the lenses from the lens supports.  
Remove the four screws of each lens and pull the lens out toward you.



**4** Mount the washers on the two screws attached at the bottom of the lens and reinstall the lenses, aligning them with the appropriate hole on the lens spacers.



**5** Fasten the four screws for each lens.

**6** Reinstall the power block and HV block.

**7** Reinstall the hood and top panel.

### Notes

- Even if you install the projector using the rear projection, use the CRT spacers and lens spacers for front projection.

- Not to drop the washer inside the projector. If you do so, be sure to pick it up.

1-5. NOTES ON SCREEN

**Screen Size**

The screen size defines the size of a screen using the diagonal length in inches while the aspect ratio of the screen is 4:3. The ratio of the screen height, width, and diagonal is 3:4:5. You can calculate the screen height and width from the screen size (inches) as follows.

Height = Screen size  $\times$  25.4  $\times$  3/5

Width = Screen size  $\times$  25.4  $\times$  4/5

**Screen size and dimensions**


| Screen size (Inches)<br>(Diagonal) | Height (mm) | Width (mm) |
|------------------------------------|-------------|------------|
| 70                                 | 1067        | 1422       |
| 72                                 | 1097        | 1463       |
| 80                                 | 1219        | 1626       |
| 100                                | 1524        | 2032       |
| 120                                | 1829        | 2438       |
| 150                                | 2286        | 3048       |
| 180                                | 2743        | 3058       |
| 200                                | 3048        | 4064       |
| 250                                | 3810        | 5080       |
| 300                                | 4572        | 6096       |

**Screens Whose Aspect Ratio Is Not 3:4**

**When the height is greater**

Calculate the approximate screen size from the screen height as shown below. Install the projector and screen in accordance with the screen size obtained.

--- : Screen whose aspect ratio is 3:4




Screen size = Height (mm)  $\times$  5/3  $\div$  25.4

**Example:** When the screen height is 1500 mm  
 $1500 \times 5/3 \div 25.4 = 98$  inches

**When the width is greater**

Calculate the approximate screen size from the screen width as shown below. Install the projector and screen in accordance with the screen size obtained.

--- : Screen whose aspect ratio is 3:4




Screen size = Width (mm)  $\times$  5/4  $\div$  25.4

**Example:** When the screen width is 2000 mm  
 $2000 \times 5/4 \div 25.4 = 98$  inches

## Types of Screen


### Front projection screen for floor installation

The bead screen is recommended. A screen of this type reflects the brightest light to the incidence position. The Sony VPS-100F1 and VPS-120F screens are bead screens.




### Front projection screen for ceiling installation

The silver screen is recommended. You can get a picture that is two to four times brighter.




### Rear projection screen

A screen manufactured using two sheets, the *fresnel* and *lenticular*, is recommended for a bright and clear full-screen picture projection. The Sony VPS-700R rear screen is this type with black stripes that can produce high quality contrast by blocking out outside light. The illustration shows the horizontal viewing area for a screen of this type.





**Aluminum (Curved) screen**

When you install the projector in a narrow room, you can get a brighter picture using the aluminum screen for both floor and ceiling installations. An aluminum screen has a narrow directivity, resulting in a limited viewing area. However, it allows you to get a very bright picture in a narrow room. Note that a screen of this type can easily be affected by outside light and therefore requires consideration for a proper lighting system arrangement in the room. The Sony VPS-72HG1 and VPS-100HG1 screens are aluminum screens.




The illustrations below show the horizontal viewing area for a screen of this type.



**White screen**

When a number of viewers watch picture projection in a wide area, a picture that appears equally bright from all parts of the room can be obtained using the white screen for both floor and ceiling installations. Note that you will not be able to get a clear picture in this case unless the room is dark.




## 1-6. DYNAMIC PICTURE SETTING


When the video signal is input, you can obtain the picture of high quality contrast by switching the DYNAMIC PIC SW on the BA board. (The switch is set to OFF at the factory.)

**1** Open the hood.


**2** Remove the three screws on the upper part of the connector panel frame to remove.



**3** Remove the two screws on the upper cover of the connector panel and remove the cover.




**4** Pull the BA board out toward you and set the SW1: DYNAMIC PIC SW on the board to ON.



SW1: DYNAMIC PIC SW

→ ON



**5** Replace the parts following steps 4 to 1 in reverse.

# **Connections**

## **Contents**

Connecting to the projector directly

Connecting video equipment and a computer equipped with the RGB output

Connecting when the projector is away from other equipment

Using the IFU-1271 interface unit

Using the PC-1271 switcher

Connecting more than four input sources


5BNC mode setting

## 1-7. CONNECTING TO THE PROJECTOR DIRECTLY

You can expand the system connections by installing the optional interface board to INPUT A or B, or in combination with the examples mentioned below.

### Connecting Video Equipment and a Computer Equipped with the RGB Output

#### When a color monitor is not connected to the computer




#### Notes

- The VIDEO connector is disconnected automatically when a cable is connected to the Y/C connector.
- The external sync signal has priority over the internal sync signal. However, when the external sync signal is incomplete, the internal sync signal has priority.


**When a color monitor is connected to the computer**

Use the IFU-1271 interface unit.



**When a computer is connected to the projector using the SIC-series connecting cable**

Install the optional interface board to the INPUT A or INPUT B section.




**Note**  
Use the standard SIC cable. Be sure not to extend the length of the cable. Otherwise, the picture may be distorted.

1-8. CONNECTING WHEN THE PROJECTOR IS AWAY FROM OTHER EQUIPMENT


Use the IFU-1271 interface unit or the PC-1271 switcher (not supplied).

**Using the IFU-1271 Interface Unit**



- If a color monitor is used, connect the RGB input on the monitor to the RGB OUT connectors on the IFU-1271 interface unit.

### Connecting the computer using the SIC-series connecting cable



Use the appropriate cable for connection between the projector and the IFU-1271 referring to the following table.


| Cable length    | Up to 10 m       | Up to 25 m | Up to 50 m |
|-----------------|------------------|------------|------------|
| Cable thickness | 1.5C-2V (SIC-10) | 3C-2V      | 5C-2V      |

### Using the PC-1271 Switcher

Connect the projector to the PC-1271 switcher using the CCQ BRS connecting cable.

### 1-9. CONNECTING MORE THAN FOUR INPUT SOURCES

When you use the PC-1271 switcher (not supplied), you can connect easily more than four input sources. You can select up to 16 inputs by pressing the SWITCHER/INDEX keys on the Remote Commander or the SWITCHER keys on the control panel of the projector.



Use the appropriate cable among the following table.

| 1 m     | 2 m      | 5 m      | 10 m      | 15 m     | 25 m      | 50 m      |
|---------|----------|----------|-----------|----------|-----------|-----------|
|         | CCQ-2BRS | CCQ-5BRS | CCQ-10BRS |          | CCQ-25BRS | CCQ-50BRS |
| SIC-M-1 |          | SIC-M-5  |           | SIC-M-15 | SIC-M-25  | SIC-M-50  |

**Notes**

- Insert the female and male plugs of the CCQ-BRS cable correctly.
- The CCQ-BRS cable can be extended to maximum 50 m.
- The equipment can be connected to the VIDEO IN and the RGB IN connectors even when the switcher is connected.

**Using the SWITCHER/INDEX (SWITCHER) keys**

When you use the Remote Commander, set the SWITCHER/INDEX select switch to SWITCHER. Press the number key from 1 to 8 to select the input number of the switcher. The SECOND key is used when two switchers are connected. To control the second switcher (whose SINGLE/REMOTE2/SECOND switch is set to SECOND), first press SECOND and then the number key.


## 5BNC Mode Setting

When a high-resolution computer, such as a workstation with a horizontal scanning frequency of more than 50 kHz, is connected to the projector through the PC-1271 switcher from 25 — 50 m away, change the 5BNC mode and connect to the REMOTE 1 connector and the RGB IN connectors on the projector.


### Selecting the internal switch

**1** Open the hood.


**2** Remove the three screws on the upper part of the connector panel frame and remove it.



**3** Remove the two screws on the upper part of the VIDEO connector panel and remove the cover.





**4** Remove the screws on the left and right side of the VIDEO connector panel and pull the panel out toward you.



To be continued


- 5** Set the SW1:5BNC SW to ON.  
The switch is on the BB board of the connector panel.



- 6** Return the projector to the original condition.  
Follow steps 1 to 4 in reverse.

- 7** Connect the REMOTE 1 connectors of the projector and switcher with the CCQ BRS cable.


- 8** Connect the RGB IN connectors of the projector and the MONITOR OUT connectors of the switcher with five BNC cables.



## 1-10. BEFORE STARTING ADJUSTMENT

**Before you perform the registration adjustment, make sure to warm up the projector for 20 minutes after power ON.**

For optimum performance, the projector is designed with a warm-up period of about twenty minutes after you turn on the power. During this period, it displays a white screen with the message shown below. Thirty-five seconds after the warming up starts, the message will disappear temporarily and will be subsequently displayed at 30-second intervals for 5 seconds at a time.



If you want to see the picture input from the equipment connected to the projector at once after completing the adjustment, press the PAGE key. You may set the projector for a shorter warming up period or for immediate projection of the picture input.


## 1-11. REMOTE CONTROL OPERATION

All of the adjustments except lens focus can be carried out by using the supplied RM-1271 Remote Commander. Normally, the adjustment keys on the Remote Commander are provided with a protection and are inoperable. Before making adjustments, cancel the protection.


Since the RM-1271 is an infrared type, it can be used without a wire. However, in order to correctly control the projector, connecting the projector and the Remote Commander with the remote control cable supplied is recommended.

### Preparation

- 1** Insert three size AA (R6) batteries with the polarity lined up correctly.
- 2** Connect the Commander to the projector.
- 3** Press the MAIN POWER switch on the projector and then press the POWER ON key on the Commander.
- 4** Remove the panel cover of the adjustment keys.




- 5** Keep pressing the TEST key for 5 seconds. The display will appear.



- 6** Press the ▲ key. The protection on the adjustment keys is cancelled and the adjustment keys will function. After adjustment, activate the protection again

## Keys on the Commander



### 1 LIGHT button

Press to light key indicators.  
If the keys are not operated within about 30 seconds, the light automatically goes out.

### 2 Transmission indicator

The light goes on each time a key is pressed.  
When the indicator does not light, replace the batteries.

### 3 MEMORY key

Press to store various adjustment data into memory.

### 4 STATUS ON/OFF key

Press **OFF** to eliminate the "On-Screen display".  
Press **ON** to restore the on-screen display.  
**Note:** The PAGE display appears even when the **OFF** key is pressed.

### 5 SECAM key

When SECAM signal is input to the projector and you cannot get normal color, press this key. Press again to switch over to the other standard system sources, NTSC or PAL.

### 6 C.B. (clear blue) key

Press to make the blue color clear in RGB mode. Press again to restore the normal condition.

### 7 RGB SIZE key

Press to adjust the size of the picture for the video and RGB signal inputs.  
Press this key to enter the size adjustment mode.  
The size adjustment is performed using the four arrow keys.

- ◀ . . . . to reduce the horizontal size
- ▶ . . . . to expand the horizontal size
- ▲ . . . . to expand the vertical size
- ▼ . . . . to reduce the vertical size

### 8 RGB SHIFT key

Press to adjust the shift of the picture for the RGB signal input.  
Press this key to enter the size adjustment mode.  
The shift adjustment of the picture is performed using the four arrow keys. The picture shifts according to the direction of the arrow.

#### Note

This key does not function with the video signal input.

### 9 CENT R/B keys


Press to enter the centering adjustment mode of the red and blue.

**CENT R:** Press to enter the red centering adjustment mode.

**CENT B:** Press to enter the blue centering adjustment mode.

Centering adjustments are performed using the four arrow keys.

## Keys on the Commander



- 10 Arrow keys**  
The keys are used for various adjustment functions.
- 11 PJ MUTE keys**  
**PIC:** Press to cut off the picture. To restore the picture, press it again or CONTR +.  
**AUDIO:** Press to cut off the sound. To restore the sound, press it again or VOL +.
- 12 POWER ON/OFF keys**  
Press to turn on and off the projector.
- 13 PICTURE CONTROL keys**  
Press to adjust picture condition: hue, sharpness, brightness, color, and contrast. Press RESET to restore the standard levels.
- 14 VOL (volume) +/- keys**  
Press to adjust volume.  
+ : to increase volume  
- : to decrease volume
- 15 ADJ R/G/B (adjust red/green/blue) keys**  
Press to select color to be adjusted when adjusting the registration.  
R . . . Red signal  
G . . . Green signal (Servicing only. If you change the green signal setting, perform the factory reset operation.)  
B . . . Blue signal
- 16 BLKG (blanking) key**  
Press to enter the blanking adjustment mode. The adjustment can be performed using the four arrow keys.
- 17 POSITION +/- keys**  
Used for zone adjustment and the blanking adjustment.
- 18 W/B (white balance) key**  
Press to enter the white balance adjustment mode.  
**BIAS:** For cut off adjustment  
**GAIN:** For drive adjustment

**19 REGISTRATION keys  
SIZE/LIN/SKEW/BOW/KEY/PIN/ZONE**  
Press to select the desired item for registration adjustment. The registration adjustment is performed using the four arrow keys, ADJ keys and POSITION +/- keys. For details, see "Registration Adjustment."

**20 NORMAL key**  
Press to cancel the test patterns or serviceman control mode.

**21 TEST key**  
Press to display the internal test patterns. Each press of this button displays 8 patterns sequentially. In registration and white balance adjustment mode, appropriate patterns will be displayed for each adjustment.

**22 CUT OFF keys**  
Press to select the color to be turned off when adjusting the registration. Press again to turn on the color.  
R . . . Red signal  
G . . . Green signal  
B . . . Blue signal

**23 SWITCHER/INDEX keys**  
**When the SWITCHER/INDEX select switch is set to SWITCHER**  
When the PC-1271 switcher is connected, select the input from the switcher. The SECOND key is used when two switchers are connected. To select the input from the second switcher (when the switcher's SINGLE/REMOTE 2/SECOND switch is set to SECOND), press the number keys after pressing SECOND. Number key 9 does not operate.  
**When the SWITCHER/INDEX select switch is set to INDEX**  
These keys function when the IFB-101 interface board (not supplied) is attached and multiple projectors are connected. For details, refer to the instructions manual of the IFB-101.

**24 INPUT SELECT keys**  
Press to select the input signal.  
**VIDEO:** to select the signal input from the VIDEO IN (Y/C or VIDEO) connectors  
**A:** to select the signal input from the RGB IN connectors  
**B:** to select the signal input from the connectors of B section (when the optional interface board is attached)

**25 PAGE key**  
Press to display and switch the following five on-screen displays.

**PAGE 1:** Displays STATUS ON/OFF, PIC MUTE ON/OFF, AUDIO MUTE ON/OFF, CLEAR BLUE ON/OFF, and SECAM ON/OFF.

**PAGE 2:** Displays the picture conditions; contrast, color, brightness, sharpness and hue and volume level.

**PAGE 3:** Displays the color temperature level, clamp setting and vertical shift range.

**PAGE 4:** Displays the input signal conditions; fH, fV, H/C-sync, V-sync, Sync on Green, input signal and registration memory block assignment.


**PAGE 5:** Displays the current use time of each cathode-ray tube (CRT) and the baud rate setting for communicating via the RS-422.

**26 ENTER key**  
This key functions when the IFB-101 interface board (not supplied) is attached and multiple projectors are connected. For details, refer to the instructions manual of the IFB-101.

**27 SWITCHER/INDEX select switch**  
Selects the SWITCHER/INDEX key function. When using as the switcher input selector, set to SWITCHER. When attaching the IFB-101 interface board at the rear of the projector and controlling multiple projectors, set to INDEX.

1-12. PROJECTING

You can also use the keys on the control panel with the same name as the Remote Commander to operate the projector.



- 1** Depress the MAIN POWER switch of the projector (  ON).
- 2** Turn on the power by pressing the POWER ON key on the Remote Commander or the control panel of the projector.
- 3** Turn on the connected equipment.
- 4** Select the input signal to be projected by pressing the INPUT SELECT key.  
**VIDEO:** to select the signal input from the VIDEO IN (Y/C or VIDEO) connectors  
**A:** to select the signal input from the RGB IN connectors  
**B:** to select the signal input from the connectors of "B" section (optional interface board)  
 When the PC-1271 switcher is connected, set the SWITCHER/INDEX select switch to SWITCHER and then select the input with the SWITCHER/INDEX number keys. If two switchers are connected, first press the SECOND key and then the number key.
- 5** Adjust the picture and sound.
- 6** To turn off the power, press the POWER OFF key on the Remote Commander or the control panel of the projector, then press the MAIN POWER switch of the projector.

Press the STATUS OFF key.  
However, PAGE is displayed even in OFF mode.  
To restore the on-screen display, press the STATUS ON key.

**To mute the sound**

Press the PJ MUTE AUDIO key. To restore the previous sound level, press the PJ MUTE AUDIO key again or VOL + key.

**To cut off the picture**

Press the PJ MUTE PIC key. To restore the previous brightness level, press the PJ MUTE PIC key again or CONTR + key.

Press the SECAM key. Press again to switch over to other standard system sources, NTSC or PAL.  
If you wish to keep the C.B. ON/OFF or SECAM ON/OFF setting, press the MEMORY key


- You can adjust the size of the picture using the RGB SIZE and arrow keys.
- The shift of the picture cannot be adjusted.

- To make the blue color clear, press the C.B. key. Press again to restore the normal condition.
- If necessary, adjust the size and shift of the picture using the RGB SIZE/SHIFT and arrow keys.

## Adjusting the Picture and Sound

Use the VOL and PICTURE CONTROL keys on the Remote Commander.

The adjustment levels are digitally displayed on the screen having a range of MIN, 1, 2, . . . , 98, 99, MAX.



**VOL +/- keys**    +: to increase volume  
                              -: to decrease volume

**CONTR +/- keys**    +: to increase picture contrast  
                              -: to decrease picture contrast

**COLOR +/- keys**    +: to increase color intensity  
                              -: to decrease color intensity

**BRT +/- keys**        +: to make the picture brighter  
                              -: to make the picture darker

**SHARP +/- keys**    +: to make the picture sharper  
                              -: to make the picture softer


**HUE +/- keys**        +: to make skin tones greenish  
                              -: to make skin tones purplish

- The COLOR, SHARP and HUE controls do not function on the picture input from the RGB IN connectors.
- The HUE control does not function with the PAL or SECAM color source.

### To restore the factory preset levels

Press the RESET key.


The factory preset levels will be displayed on the screen.



## To Display the Current Control Settings and Conditions

Press the PAGE key for displaying the following five on-screen displays. Adjustment can also be done on PAGE 1, 2, 3 and 5. The displays will switch as follows every time the PAGE key is pressed:

Page 5 will be displayed only during the service-man mode.



### PAGE 1

|                      |                |
|----------------------|----------------|
| <b>PAGE 1</b>        | <b>INPUT-A</b> |
| <b>USER PRESET</b>   |                |
| <b>STATUS :</b>      | <b>ON</b>      |
| <b>PIC MUTE :</b>    | <b>OFF</b>     |
| <b>AUDIO MUTE :</b>  | <b>OFF</b>     |
| <b>CLEAR BLUE :</b>  | <b>OFF</b>     |
| <b>SECAM :</b>       | <b>---</b>     |
| <b>NEXT : [PAGE]</b> |                |

**STATUS: ON/OFF**

The setting is stored even if the power is turned off. When on-screen display does not appear, check if STATUS ON is displayed.

**PIC MUTE: ON/OFF**

Whenever the power is turned on, PIC MUTE is set to OFF.

**AUDIO MUTE: ON/OFF**

Whenever the power is turned on, AUDIO MUTE is set to OFF.

**CLEAR BLUE: ON/OFF**

The setting can be changed for each input signal which differs in any of the items indicated in PAGE 4.

**SECAM: ON/OFF**

When the PAL color signal is projected with this item set to ON, the picture is displayed in black and white. Make sure to set to OFF when the SECAM color source is not connected.

"- -" indicates that the control does not function with the current input signal.

To change the settings, adjust with the appropriate key.

### PAGE 2

|                      |                |
|----------------------|----------------|
| <b>PAGE 2</b>        | <b>INPUT-A</b> |
| <b>USER CONTROL</b>  |                |
| <b>CONTR :</b>       | <b>80</b>      |
| <b>COLOR :</b>       | <b>---</b>     |
| <b>BRT :</b>         | <b>50</b>      |
| <b>SHARP :</b>       | <b>---</b>     |
| <b>HUE :</b>         | <b>---</b>     |
| <b>VOL :</b>         | <b>50</b>      |
| <b>NEXT : [PAGE]</b> |                |

The picture conditions; contrast, color, brightness, sharpness, hue and volume level are displayed. The levels can be changed independently for the signal input from different input connectors. (You can check the input connector from the message displayed in the upper right corner of the screen).

"- -" indicates that the control does not function with the current input signal. (In this case, the input signal is RGB.) To change the levels, adjust with the VOL and PICTURE CONTROL keys.

PAGE 3

PAGE 3 INPUT-A  
SYSTEM PRESET  
COLOR TEMPERATURE:  
9300 6500 3200 PRESET  
CLAMP: AUTO SonG H/C H.P  
V-SHIFT: WIDE NARROW

SELECT:   
NEXT: [PAGE]

The color temperature, clamp and vertical-shift adjustment range settings are displayed.

The selected item blinks in green.

To change the setting, adjust by pressing ◀, ▶, ▲ and ▼ keys.

**COLOR TEMPERATURE: 9300/6500/3200/PRESET**

Normally, set to "6500". If you want to make white color bluish, set to 9300, and if you want to make white color reddish, set to 3200.

**V-SHIFT: WIDE/NARROW**

Normally set to WIDE. When some particular RGB signal sources are connected, the picture may be distorted vertically. In such case, set to NARROW. Adjustable range in the lower direction will be narrow.

For details of the clamp setting, see "If the luminance of the picture is incorrect—clamp setting".

If you wish to keep the current setting, press the MEMORY key.

**Note**

"CLAMP" and "V-SHIFT" are not displayed when the input mode is VIDEO.

PAGE 4

PAGE 4 INPUT-A  
INPUT INFO  
fH: 31.5kHz  
fV: 60.0Hz  
H/C-SYNC: POS  
V-SYNC: POS  
SYNC ON G: NEG  
INPUT SIGNAL: RGB  
REGI BLOCK: NO. 3  
EXIT: [PAGE]

The signal input conditions are displayed.

fH: The horizontal frequency of the input signal

fV: The vertical frequency of the input signal

**H/C-SYNC:** The polarity of the H/C-SYNC

**V-SYNC:** The polarity of the V-SYNC

**SYNC ON G:** The polarity of the SYNC on the Green

**POS:** positive  
**NEG:** negative\*  
--: no input

\* When POS (NEG) is displayed in green:

The picture is being projected using its sync signal.

When POS (NEG) is displayed in white:

The picture is being projected without using its sync signal.

**INPUT SIGNAL:** The current input signal.

**Y/C:** S video input signal from VIDEO IN

**RGB:** RGB input signal

**NTSC:** NTSC input signal from VIDEO IN

**PAL:** PAL input signal from VIDEO IN

**B&W:** Black and white input signal from VIDEO IN

**Internal oscillation mode:** Internal oscillation mode (No signal is input.)

**REGI BLOCK:** The registration memory block number in which the input signal is assigned.

**PAGE 5** **INPUT-A**  
**OTHER ITEMS**

1. CRT TIMER DISPLAY
2. BAUD RATE PRESET

**SELECT:**    
**ENTER:**   
**EXIT:** [PAGE]

The two different pages, the current use time of the cathode-ray tubes and the baud rate\* setting can be selected to display.

The selected item blinks in green. To display either page, select the item with the ▼ and ▲ keys, and then press the ► key.

\* The baud rate means the signaling speed when the RS-422 is connected to the projector. The baud rate of the projector should be set to a rate equal to that of the connected computer.

When the "1. CRT TIMER DISPLAY" is selected

**PAGE 5-1** **INPUT-A**  
**CRT TIMER**  
**DISPLAY MODE**  
**RED:** 0005 hours  
**GREEN:** 0005 hours  
**BLUE:** 0005 hours

**EXIT:** [PAGE]

The use time of each cathode-ray tube (CRT) is displayed in one-hour intervals.

**RED:** Use time of red CRT

**GREEN:** Use time of green CRT

**BLUE:** Use time of blue CRT

When the "2. BAUD RATE PRESET" is selected

**PAGE 5-2** **INPUT-A**  
**RS422**  
**COMMUNICATION**  
**BAUD RATE PRESET MODE**

38.4k 19.2k 9600 4800

**SELECT:**     
**EXIT:** [PAGE]

The baud rate setting for communicating with the external equipment via the RS-422 is displayed.

The selected item blinks in green. To change the setting, press the ◀ and ► keys.

**Note**

When using with the Sony VPX-010M projector auto set-up system, set to 38.4k.

## Adjusting the Size And Shift of the Picture

If necessary, adjust the size and shift of the picture using the RGB SIZE/SHIFT and arrow keys.

You can also adjust the size of the picture input from the VIDEO IN connectors using the RGB SIZE and arrow keys.


The SHIFT of the video input signal cannot be adjusted.

If you wish to keep the current adjustment setting, press the MEMORY key.

When the setting is saved in the memory, the display disappears.


**RGB/VIDEO SIZE ADJUSTMENT**

If the size of the picture does not fit the screen, adjust RGB SIZE.  
In this case the RGB signal is input.



- 1 Press the RGB SIZE key.**
- 2 Adjust by pressing the arrow keys so that the picture fits the screen.**
  - ◀ to reduce horizontal size
  - ▶ to expand horizontal size
  - ▲ to expand vertical size
  - ▼ to reduce vertical size


If the RGB picture needs to be shifted to fit the screen, adjust RGB SHIFT.




- 1 Press the RGB SHIFT key.**
- 2 Adjust by pressing the arrow keys so that the picture fits the screen.**  
The picture shifts according to the direction of the arrow.

**1** Press the RGB SIZE or SHIFT key.

**2** Press the ◀ and ▶ keys simultaneously.  
The following on-screen display appears on the screen.



**3** Press the ▲ key.  
The following on-screen display appears on the screen to confirm that  
resetting was completed.  
To keep the current setting instead of resetting, press the ▼ key.




## To Store the Adjustment Levels


If you wish to save the picture adjustment changes, you must store them in the memory.  
The following conditions can be stored:

SECAM ON/OFF setting  
CLEAR BLUE (C.B.) ON/OFF setting  
COLOR TEMPERATURE, CLAMP and V-SHIFT adjustment settings on  
VIDEO and RGB SIZE adjustment levels  
RGB SHIFT adjustment level

- 1 After the adjustment, press the MEMORY key.**  
The following on-screen display appears to indicate that storing has begun. While the display is on, no other key will function.




- 2** The following on-screen display appears to confirm that storing has been completed.




### 1-13. CENTERING ADJUSTMENT

The three colors, red, green and blue must converge for proper projection. If they do not converge, centering adjustment is necessary.




**1** Press the **MAIN POWER** switch of the projector and press the **POWER ON** key of the Remote Commander.

**2** Press the **CENT R** key. The built-in cross hair test pattern will be displayed and the red line will be operable.




**3** Press the arrow keys to move the red line until the red and green lines converge and are seen as yellow.


The red line will move according to the direction of the arrow.



**4** Press the **CENT B** key.  
The blue line will be operable.



**5** Press the arrow keys to move the blue line until the blue and yellow lines converge.  
When all three color lines converge, the test pattern will be seen as white.











**6** Press the **MEMORY** key.  
The normal display is restored.

1-14. ADJUSTMENT DISPLAYS AND TEST PATTERNS


**Test Patterns**

In each adjustment mode, an appropriate test pattern will be displayed. In addition, other test patterns can be displayed by pressing the TEST key.

**All the test patterns**

|   |  |
|---|--|
| <p><b>Cross hair</b></p>         | <p><b>H</b></p>         |
| <p><b>Hatch (9 × 9)</b></p>     | <p><b>White</b></p>    |
| <p><b>Hatch (reverse)</b></p>  | <p><b>Window</b></p>  |
| <p><b>Dot</b></p>              | <p><b>PLUGE*</b></p>  |

\*PLUGE = Picture Line Up Generating Equipment



The outside bold line stands for the edge of the screen.



## 1-15. ADJUSTMENT PROCEDURES

Perform each adjustment with the supplied Remote Commander, first with no input source connected. After the adjustment, save the data. Next, perform the fine adjustments for each input signal.

**Follow the steps below.**

**1** Prepare the Remote Commander.



**2** Perform adjustments with no input.

- Focus
- Registration



**3** Save the adjustment data as standard data.



**4** Perform the fine adjustments for each input signal.

- Centering
- Registration
- RGB size and shift
- Blanking
- White balance



**5** Save the adjustment data.



**6** Activate the protection on the Remote Commander again.



**7** Adjust the picture.

## 1-16. LENS FOCUS ADJUSTMENT

### Procedure

**1** Remove the top panel.



**2** Set the Remote Commander to the serviceman adjustment mode by removing the panel cover on the adjustment keys.



**3** Select the input with no input source connected.  
(NO INPUT mode)



**4** Display the H-pattern.



**5** Set both CONTR (contrast) and BRT (brightness) levels to 50.



**6** Adjust the green focus.



**7** Adjust the red focus.



**8** Adjust the blue focus.



**9** Adjust the electric focus.  
(if necessary)




Proceed to the registration adjustment.


## Adjustment

### 1 Remove the top panel.


- ① Push the part marked "PUSH" on the control panel cover to open.



- ② Loosen two screws (black M4 x 16) of the control panel and slide the top panel in the direction of the arrow.




- ③ Open the top panel towards the lens section to detach.




### 2 Make the adjustment keys on the Remote Commander operable.

- 3** **Select the input with no input source connected. (NO INPUT mode)**  
 Press the INPUT SELECT A, B or VIDEO key. Or, set the SWITCHER/INDEX select switch to SWITCHER and then from among the number keys from 1 to 8, press a key with no input source connected.  
 Make sure that "NO INPUT" is displayed on the screen.




**4** Press the TEST key on the Commander five times.  
An H-pattern will appear.





**5** Press PICTURE CONTROL CONTR and BRT +/- keys to set their adjustment levels to 50.

**6** Adjust the green focus.

- ① Press the CUT OFF R and B keys to display the green signal only.
- ② Adjust the center-focus.  
Loosen the G1 screw, slide it so that the letters H at the center of the screen is in optimum focus, and then tighten the screw.
- ③ Adjust the corner-focus.  
Loosen the G2 screw, slide it so that the letter H at the four corners (pay attention to the areas ) are equally in focus, and then tighten the screw.



- ④ Repeat steps ② and ③ two or three times.



**Lens focus adjustment hint**

The letter H is made up of dots. If it is in focus, the dots will be clearly seen as in the illustration.



## 7 Adjust the red focus.

- ① Press the CUT OFF G and B keys to display the red signal only.
- ② Adjust the red center-focus using the R1 screw following the same procedure as for the green focus.
- ③ Adjust the red corner-focus using the R2 screw following the same procedure as for the green focus.
- ④ Repeat steps ② and ③ two or three times.

## 8 Adjust the blue focus.

- ① Press the CUT OFF G and R keys to display the blue signal only.
- ② Adjust the blue center-focus using the B1 screw following the same procedure as for the green focus.
- ③ Adjust the blue corner-focus using the B2 screw following the same procedure as for the green focus.
- ④ Repeat steps ② and ③ two or three times.

The lens focus adjustment is complete.  
Proceed to the registration adjustment.

### Notes

- When you cannot see the letter H clearly as seen in step 6 with the green and red focus adjustments, perform the electric focus adjustment.
- If the focus of the upper, lower, left and right parts is not equal, check that the installation of the projector is correct.

## Electric Focus Adjustment

When you cannot obtain sharp focus with the lens focus adjustment, perform only the green and red electric focus adjustments using the controls as shown in the illustration.



**1** Remove the top panel.

**2** Press the TEST key five times to display the H-pattern.

**3** Press the PICTURE CONTROL RESET key to reset the CONTR level to 80 and the BRT level to 50.

**4** Adjust the green electric focus.

- ① Press the CUT OFF R and B keys to display the green signal only.
- ② Adjust focus by turning the G control.



**5** Adjust the red electric focus.

- ① Press the CUT OFF G and B keys to display the red signal only.
- ② Adjust focus by turning the R control.

### Hint 1

Since the focus adjustment level varies with brightness of the screen, set PIC CONTROL to the factory preset levels.

### Hint 2

In the case of a high-resolution picture, when it is projected and the adjustment is made, even better focusing is possible. In this case, also, set PIC CONTROL to the factory preset levels.

### Blue electric focus adjustment

The blue electric focus is adjusted at the factory. If it is further adjusted, the white balance has to be also readjusted. Never adjust the blue electric focus.

## 1-17. REGISTRATION ADJUSTMENT

Display the test pattern on the screen and adjust the registration.

Perform green, red and blue adjustments in this order to converge the three colors.

### Procedure

**1** Mark the center of the screen.



**2** Set the Remote Commander to the serviceman adjustment mode.



**3** Select the input with no input source connected.  
(NO INPUT mode)



**4** Reset the data to the factory preset level.  
(Only when the adjustment data has been saved before)



**5** Check that the shift of a test pattern is correct.  
(Only when the washers were inserted)



**6** Release blanking adjustment.



**7** Adjust the green registration.

- ① Centering adjustment
- ② SIZE and LIN adjustments
- ③ SKEW and BOW adjustments
- ④ KEY and PIN adjustments



**8** Adjust the red registration.

- ① Centering adjustment
- ② SIZE and LIN adjustments
- ③ SKEW and BOW adjustments
- ④ KEY and PIN adjustments
- ⑤ ZONE adjustment



**9 Adjust the blue registration.**

- ① Centering adjustment
- ② SIZE and LIN adjustments
- ③ SKEW and BOW adjustments
- ④ KEY and PIN adjustments
- ⑤ ZONE adjustment



**10 Adjust blanking.**



**11 Save the adjusted data as standard data.**



**12 Perform fine adjustments for each input signal**

- ① Adjustment of video input signal
- ② Adjustment of RGB input signal
- ③ White balance adjustment



**13 Activate the protection on the Remote Commander.**




**14 Adjust the picture.**



**Complete.**

# Keys for Registration Adjustment




- Arrow keys
- CUT OFF R/G/B keys
- ADJ R/G/B (Adjust red/green/blue) keys
- TEST key
- NORMAL key
- REGISTRATION keys (SIZE/LIN/SKEW/BOW/KEY/PIN/ZONE)
- POSITION keys

## Identifying the REGISTRATION keys

| Indications on the Commander | Adjustment Items |
|------------------------------|------------------|
| SIZE                         | size             |
| LIN                          | linearity        |
| SKEW                         | skew             |
| BOW                          | bow              |
| KEY                          | keystone         |
| PIN                          | pincushion       |
| ZONE                         | centering, zone  |


## Preparation

- 1 Mark the center of the screen.**  
Measure the height and width of the screen to decide the center.  
Marking five points as illustrated with white tape will help you adjust registration.



- 2 Set the Remote Commander to the serviceman adjustment mode.**

- 3 Select the input with no input source connected. (NO INPUT mode)**  
Press the INPUT SELECT A, B or VIDEO key on the Remote Commander. Or, set the SWITCHER/INDEX select switch to SWITCHER and then from among the number keys from 1 to 8, press a key with no input source connected. Make sure "NO INPUT" is displayed on the screen.




- 4 Reset the standard data.**  
(Only when the registration adjustment has been performed and the data has been saved before)


- 5 If you install the projector with the washer inserted, check that the distance between the center of the screen and the center of the cross hair pattern is appropriate.**

- 1 Press the TEST key to display the cross hair pattern.
- 2 Press the ADJ G key.
- 3 Measure the distance (B) between the center of the screen and the center of the cross hair pattern. (See the illustrations below.)  
If the distance is nearly equivalent to that given in the "List of washers used for non-standard installation", your installation and washer insertion are correctly performed. If the distance is not equivalent, adjust the angle of optical axis.

### Floor installation




### Ceiling installation




### Notes

- The center of the screen and the center of the cross hair pattern can be aligned by performing the centering adjustment.
- When the angle of optical axis is smaller, the hatch pattern becomes trapezoidal. Perform the keystone adjustment to correct the distortion.

### Floor installation




### Ceiling installation



# Releasing Blanking Adjustment

The registration adjustment is difficult if the entire test pattern is not visible. Follow the steps below to make the whole test pattern visible.



**2** Press the **TEST** key once.  
The hatch pattern is displayed.

**3** Press the **POSITION +/-** keys to select the part to be adjusted.  
When the + key is pressed, the position will change as follows:



UPPER → LOWER → LEFT → RIGHT

When the - key is pressed, the position will change in the reverse of the above order.

**4** Press the arrow keys until "Overflow!" is displayed on the screen for each position.

▲: UPPER, ▼: LOWER, ◀: LEFT, ▶: RIGHT

**1** Press the **BLKG** key to enter the blanking adjustment mode.



**What is blanking?**

Blanking is masking the picture. The picture size of this projector is adjusted at the factory to fit the 120-inch screen. According to the installation method, it is necessary to reduce or increase the masking to fit the picture to the screen. Here, reduce the masking to the minimum (the picture is projected at the largest size), and after the registration adjustment is complete, perform the blanking adjustment to fit the screen used.

**Note**

There may be a rainbow-like vertical band on the right side or a diagonal line on the upper part of the screen. As they can be adjusted with the blanking adjustment later, leave them alone for now.

## Green Registration Adjustment

**Be sure to adjust starting with the green test pattern.**  
When adjusting green, do not perform the ZONE adjustment as far as possible. If the green ZONE adjustment is great, the adjustment of red and blue may be difficult.

### 1 Green centering adjustment


Adjust so that the center of the test pattern is aligned with the center of the screen.

- 1 Press the ZONE key.**  
The hatch pattern and the cursor are displayed.  
If the cursor is not centered, press the POSITION key to move it to the center of the screen.

- 2 Press the ADJ G key.**

- 3 Press the CUT OFF R and B keys to display green only.**

- 4 Press the arrow keys to align the center of the hatch pattern with the center of the screen.**



#### Notes


- At this time perform the ZONE adjustment only for the center zone.
- If the center of the test pattern is off the center of the screen by a large amount, check that the CRT spacers are correctly installed or the installation of the projector is correct.

**2 Green SIZE and LIN (linearity) adjustment**

Adjust the size of the displayed picture with respect to the screen, and the picture's up, down, left and right balance.

- 1 Press the LIN key.**  
You can also change to the 9 × 9 hatch pattern by pressing the TEST key.


- 2 Press the ADJ G key.**  
Pay attention only to the bold lines (the ends of the vertical and horizontal lines).




- 3 Adjust with the ◀ and ▶ keys until parts (a) on the right and left are of equal length.**



The right and left vertical lines are shifted to the left while the vertical center line remains unmoved.



The right and left vertical lines are shifted to the right while the vertical center line remains unmoved.




- 4 Press the SIZE key.**


- 5 Adjust with the ◀ and ▶ keys until parts (a) on the right and left are 15 – 20 mm long.**



The horizontal size is reduced.



The horizontal size is expanded.



- 6 If they are not aligned, press the LIN key and repeat steps 3 to 5.**


**7** If the center of the cross hair pattern is off-centered on the screen, perform the centering adjustment again and repeat steps 1 to 6 for the horizontal size adjustment.

**8** Press the LIN key.


**9** Adjust with the ▲ and ▼ keys until parts (b) at the top and bottom are of equal length.



The upper and lower horizontal lines are shifted upward while the horizontal center line remains unmoved.



The upper and lower horizontal lines are shifted downward while the horizontal center line remains unmoved.




**10** Press the SIZE key.


**11** Adjust with the ▲ and ▼ keys until parts (b) at the top and bottom are about 15 — 20 mm long.



The vertical size is expanded.



The vertical size is reduced.



**12** If they are not aligned, repeat steps 8 to 11.

**13** If the center of the cross hair pattern is off-centered on the screen, perform the centering adjustment again and then repeat steps 8 to 12 for the vertical size adjustment.


**14** After the adjustment is complete, press the MEMORY key to save the data.

**3 Green SKEW and BOW adjustments**

Display the cross hair pattern and adjust the bow-like or skew distortion of the horizontal and vertical center lines to make them parallel to the screen edges.

**A. Horizontal line adjustment**

Pay attention only to the bold line (horizontal center line).




- 1 Press BOW key.**  
You can also change to the 9 × 9 hatch pattern by pressing the TEST key.


- 2 Adjust distortion as illustrated below with the ▲ and ▼ keys.**



The right and left sides of the line are curved upward while the center remains unchanged.



The right and left sides of the line are curved downward while the center remains unchanged.




- 3 Press the SKEW key.**


- 4 Adjust distortion as illustrated below with the ▲ and ▼ keys.**



The horizontal line leans toward upper right.



The horizontal line leans toward lower right.




- 5 Repeat steps 1 to 4 until the horizontal lines become parallel to the screen edges.**

- 6 When the adjustment is complete, press the MEMORY key to save the adjustment data.**

**B. Vertical line adjustment**

Pay attention only to the bold line (vertical center line).




**1** Press BOW key.


**2** Adjust distortion as illustrated below with the ◀ and ▶ keys.



The upper and lower parts of the line are curved leftward while the center remains unchanged.



The upper and lower parts of the line are curved rightward while the center remains unchanged.




**3** Press the SKEW key.


**4** Adjust distortion as illustrated below with the ◀ and ▶ keys.



The vertical line leans leftward.



The vertical line leans rightward.



**5** Repeat steps 1 to 4 until the vertical line becomes parallel to the screen edges.


**6** When the adjustment is complete, press the MEMORY key to save the adjustment data.

## 4 Green KEY (keystone) and PIN (pincushion) adjustments

Adjust the trapezoidal distortion and the pin-cushion distortion in the vertical and horizontal directions.



### A. Horizontal line adjustment

Pay attention only to the bold lines (top and bottom horizontal lines).





- 1** Press the KEY key.  
You can also change to the 9 × 9 hatch pattern by pressing the TEST key.

- 2** Adjust distortion as illustrated below with the ▲ and ▼ keys.

|  |   |
|--|---|
| <p>▲ The lines spread apart on the right side and come together on the left side.</p>  | <p>▼ The lines spread apart on the left side and come together on the right side.</p>  |
|--|---|

- 3** Press the PIN key.

- 4** Adjust distortion as illustrated below with the ▲ and ▼ keys.


|   |   |
|---|---|
| <p>▲ The ends of the top and bottom lines spread apart.</p>  | <p>▼ The ends of the top and bottom lines come together.</p>  |
|---|---|

- 5** Repeat steps 1 to 4 until the horizontal lines become parallel to the screen edges.

- 6** When the adjustment is complete, press the MEMORY key to save the adjustment data.

**B. Vertical line adjustment**

Pay attention only to the bold lines (right and left side vertical lines).



**1** Press the **KEY** key.

**2** Adjust distortion as illustrated below with the ◀ and ▶ keys.

|   |   |
|---|---|
| <p>◀ The lines spread apart at the bottom and come together at the top.</p> | <p>▶ The lines spread apart at the top and come together at the bottom.</p> |
|---|---|

**3** Press the **PIN** key.

**4** Adjust distortion as illustrated below with the ◀ and ▶ keys.

|   |  |
|---|--|
| <p>◀ The ends of the right and left side lines come together.</p> | <p>▶ The ends of the right and left side lines spread apart.</p> |
|---|--|

**5** Repeat steps 1 to 4 to make the vertical lines parallel to the screen edges.

**6** When the adjustment is complete, press the **MEMORY** key to save the adjustment data.

The green registration adjustment is complete.  
Proceed to the adjustment for the red signal.

## Red Registration Adjustment

Adjust the red signal so that it converges with the green signal and is seen as yellow.

### 5 Red centering adjustment

Adjust so that the center of the red test pattern is aligned with that of the green pattern.

- 1** Press the ZONE key.  
The hatch pattern and the cursor are displayed.  
If the cursor is not centered, press the POSITION key to move it to the center of the screen.
- 2** Press the ADJ R key.
- 3** Press the CUT OFF B key to display green and red.
- 4** Press the arrow keys to align the center of the red hatch pattern with that of the green pattern.


**Note**

At this time perform the ZONE adjustment for the center zone only.

**6 Red SIZE and LIN (linearity) adjustments**

**1** Press the LIN key.  
You can also change to the 9 × 9 hatch pattern by pressing the TEST key.

**2** Press the ADJ R key.  
Pay attention only to the encircled portions.



-----: green    ———: red

**3** Move the red lines with the ◀ and ▶ keys until parts (a) on the right and left are of equal length.

- ◀: The right and left vertical lines are shifted to the left while the vertical center line remains unmoved.
- ▶: The right and left vertical lines are shifted to the right while the vertical center line remains unmoved.

**4** Press the SIZE key.

**5** Adjust with the ◀ and ▶ keys so that the red and green lines in the right and left encircled portions converge.

- ◀: The horizontal size is reduced.
- ▶: The horizontal size is expanded.

**6** If adjustment fails, press the LIN key and then repeat steps 3 to 5.

**7** If the center of the cross hair pattern is off-centered on the screen, perform the centering adjustment again and repeat steps 1 to 6 for horizontal size adjustment.

**8** Press the LIN key.

**9** Move the red lines with the ▲ and ▼ keys until parts (b) at the top and bottom are of equal length.

- ▲: The upper and lower horizontal lines are shifted upward while the horizontal center line remains unmoved.
- ▼: The upper and lower horizontal lines are shifted downward while the horizontal center line remains unmoved.

**10** Press the SIZE key.

**11** Adjust with the ▲ and ▼ keys so that the red and green lines at the top and bottom encircled portions converge.

- ▲: The vertical size is expanded.
- ▼: The vertical size is reduced.

**12** If adjustment fails, repeat steps 8 to 11.


**13** If the center of the cross hair pattern is off-centered on the screen, perform the centering adjustment again and repeat steps 8 to 12 for vertical size adjustment.

**14** After the adjustment is complete, press the MEMORY key to save the data.

**7 Red SKEW and BOW adjustments**

**A. Horizontal line adjustment**



Pay attention only to the bold line (horizontal center line).



- 1** Press the BOW key.  
You can also change to the 9 × 9 hatch pattern by pressing the TEST key.

- 2** Adjust with the ▲ and ▼ keys so that the vertically distorted parts ③ (or ④) on both sides are of equal length.

- ▲: The right and left sides of the lines are curved upward while the center remains unchanged.
- ▼: The right and left sides of the lines are curved downward while the center remains unchanged.





-----: green    —: red

- 3** Press the SKEW key.

- 4** Adjust with the ▲ and ▼ keys so that the vertically distorted parts ⑤ (or ⑥) on both sides are of equal length.

- ▲: The horizontal line leans toward upper right.
- ▼: The horizontal line leans toward lower right.




-----: green    —: red

- 5** Repeat steps 1 to 4 until the red horizontal line converges with the green line.

- 6** When the adjustment is complete, press the MEMORY key to save the adjustment data.

**B. Vertical line adjustment**



Pay attention only to the bold line (vertical center line).



**1** Press the BOW key.  
You can also change to the 9 × 9 hatch pattern by pressing the TEST key.

**2** Adjust with the ◀ and ▶ keys so that the horizontally distorted parts ⑨ (or ⑩) at the top and bottom are of equal length.

- ◀: The upper and lower parts of the line are curved leftward while its center remains unchanged.
- ▶: The upper and lower parts of the line are curved rightward while its center remains unchanged.





----: green —: red

**3** Press the SKEW key.

**4** Adjust with the ◀ and ▶ keys so that the horizontally distorted parts ⑪ (or ⑫) at the top and bottom are of equal length.

- ◀: The vertical line leans leftward.
- ▶: The vertical line leans rightward.



----: green —: red


**5** Repeat steps 1 to 4 until the red vertical line converges with the green line.

**6** When the adjustment is complete, press the MEMORY key to save the data.

**8 Red KEY (keystone) and PIN (pincushion) adjustments**

**A. Horizontal line adjustment**



Pay attention only to the bold lines (top and bottom lines).



**1 Press the KEY key.**  
You can also change to the 9 × 9 hatch pattern by pressing the TEST key.

**2 Adjust with the ▲ and ▼ keys so that the vertically distorted parts ① (or ②) are of equal length.**

- ▲: The lines spread apart on the right and come together on the left.
- ▼: The lines spread apart on the left and come together on the right.





----: green —: red

**3 Press the PIN key.**

**4 Adjust with the ▲ and ▼ keys so that the vertically distorted parts ③ (or ④) are of equal length.**

- ▲: The ends of the top and bottom lines spread apart.
- ▼: The ends of the top and bottom lines come together.




----: green —: red

**5 Repeat steps 1 to 4 until the red horizontal lines converge with the green lines.**

**6 When the adjustment is complete, press the MEMORY key to save the data.**

**B. Vertical line adjustment**



Pay attention only to the bold lines (right and left side lines).



**1** Press the **KEY** key.  
You can also change to the 9 × 9 hatch pattern by pressing the **TEST** key.

**2** Adjust with the ◀ and ▶ keys so that horizontally distorted parts ⑤ (or ⑥) are of equal length.

- ◀: The lines spread apart at the bottom and come together at the top.
- ▶: The lines spread apart at the top and come together at the bottom.





----: green    —: red

**3** Press the **PIN** key.

**4** Adjust with the ◀ and ▶ keys so that the horizontally distorted parts ⑨ (or ⑩) are of equal length.

- ◀: The ends of the right and left side lines come together.
- ▶: The ends of the right and left side lines spread apart.



----: green    —: red


**5** Repeat steps 1 to 4 until the red vertical lines converge with the green lines.

**6** When the adjustment is complete, press the **MEMORY** key to save the data.



**9 Red ZONE adjustment**

Perform the ZONE adjustment after the red signal has converged with the green signal as far as possible in the red adjustments 5 to 8.

- 1 Press the ZONE key.**  
The hatch pattern and the cursor are displayed.



- 2 Press the POSITION key to select the part to be adjusted.**  
When the + key is pressed, the cursor moves in the numerical order as illustrated.  
When the - key is pressed, the cursor moves in the reverse order.  
The selected position number will be displayed in the upper right corner.



- 3 Adjust the red line distortion in the area of the cursor position with the arrow keys.**

**Adjustment hint (only for VPH-1251Q)**

After you adjust the distortion in zones 6 to 9, there may still be distortion at a line inside. In this case, adjust equally noting the outermost line and one line inside.

- 4 When the adjustment is complete, press the MEMORY key to save the data.**

**The red registration adjustment is complete.  
Proceed to the registration adjustment of the blue signal.**

## Blue Registration Adjustment

Adjust the blue signal so that it converges with the red signal which has been adjusted. When the blue and red test patterns converge, the pattern is seen as magenta.

### 10 Blue centering adjustment

Adjust so that the center of the blue test pattern is aligned with that of the red pattern.

- 1** Press the ZONE key.
- 2** Press the ADJ B key.
- 3** Press the CUT OFF G key to display blue and red.
- 4** Press the arrow keys until the center of the blue hatch pattern is aligned with that of the red pattern.


#### Note

At this time perform the ZONE adjustment for the center zone only.

### 11 Blue SIZE, LIN (linearity), SKEW, BOW, KEY (keystone), PIN (pin cushion) and ZONE adjustments

Adjust so that the blue signal converges with the red signal in each adjustment. The procedures are the same as for the red registration adjustments


Make sure that "ADJ B" is displayed on the screen when adjusting the blue signal.



When the blue adjustment is complete, press the MEMORY key to save the adjustment data.

# Blanking Adjustment

After the registration adjustments, perform this adjustment to erase a rainbow-like vertical band at the right side or a diagonal line at the upper part of the screen.

|   |  |
|---|--|
| <p><b>1</b> Press the <b>BLKG</b> key.</p>  |  <p>The screenshot shows a menu titled 'BLKG ADJ' with 'UPPER' selected. At the bottom right, it displays 'ADJ: 00' and 'NEXT: 00'.</p> |
| <p><b>2</b> Press the <b>TEST</b> key.<br/>The hatch pattern is displayed.</p>  |  |
| <p><b>3</b> Press the <b>POSITION +/-</b> key to select the part to be adjusted.<br/>When the + key is pressed, the position will change as follows:<br/>UPPER → LOWER → LEFT → RIGHT<br/>When the - key is pressed, the position will change in the reverse of the above order.</p>  |  |
| <p><b>4</b> Adjust with the arrow keys.<br/>Press the ▲ and ▼ keys to adjust the UPPER and LOWER parts.<br/>A diagonal line at the upper part will be erased with the UPPER adjustment.<br/>Press the ◀ and ▶ keys to adjust the LEFT and RIGHT parts.<br/>A rainbow-like vertical band at the right side will be erased with the RIGHT adjustment.</p> |  |
| <p><b>5</b> When the adjustment is complete, press the <b>MEMORY</b> key to save the adjustment data.</p>   |  |

# Saving the Standard Registration Data


When the registration adjustments for the green, red and blue signals are complete, save the adjusted data as standard data.

**1 Press the MEMORY key. (Do not keep this key pressed.)**

The adjusted data is saved in the memory of an internal signal whose horizontal frequency is approximately 34 kHz.


**Note**

During saving, other keys do not function.



**2 Keep pressing the MEMORY key for more than 3 seconds.**

The message appears and the projector enters the standard data saving mode.



**3 Press the ▲ key (for YES).**

All the registration data will be converted into the data of the internal signal and are saved as standard data.

**Note**

If the adjustment data are saved as standard data, the registration data with other horizontal frequencies will be converted into the standard data if they have not been saved before.

## Memory structure

This projector saves the adjustment data in one of seven (for VPH-1251Q) or eight (VPH-1271Q) memories according to the horizontal frequency of the input signal. The acceptable horizontal frequency is divided into the following blocks with each block assigned to a different memory.

| Registration memory block | VPH-1251Q            | VPH-1271Q            |
|---------------------------|----------------------|----------------------|
| 1                         | fH = 15 kHz — 19 kHz | fH = 15 kHz — 19 kHz |
| 2                         | fH = 19 kHz — 24 kHz | fH = 19 kHz — 24 kHz |
| 3                         | fH = 24 kHz — 30 kHz | fH = 24 kHz — 30 kHz |
| 4                         | fH = 30 kHz — 37 kHz | fH = 30 kHz — 37 kHz |
| 5                         | fH = 37 kHz — 45 kHz | fH = 37 kHz — 45 kHz |
| 6                         | fH = 45 kHz — 50 kHz | fH = 45 kHz — 50 kHz |
| 7                         | fH = 55 kHz — 58 kHz | fH = 55 kHz — 66 kHz |
| 8                         | —                    | fH = 66 kHz — 85 kHz |

When a signal is input, its horizontal frequency is automatically detected and the memory is selected. When you perform registration adjustment with no input, the registration adjustment is performed with the projector's internal signal, whose horizontal frequency is approximately 34 kHz. So the adjustment data is saved in registration memory block 4.

If the adjustment data is saved as standard data, the factory preset data for all the memories will be calculated and changed to reflect the new registration information. By this operation the standard data in that installation condition is saved, which makes the subsequent adjustment for each input signal easier. Follow the two steps below.

- 1 After installation, perform registration adjustment with no input and save the adjustment data. Then save the adjusted data as standard data.**
- 2 Perform installation adjustment for each input signal and save the adjustment data.**

### For reference — Memory architecture

| Memory Name              | Memory Data   | How the projector recognizes data  | When data is memorized   |
|--------------------------|---|--|--|
| Channel Memory           | Picture control<br>Video SIZE   | Input connector  | When the MEMORY key is pressed<br>When the input connector is switched<br>When the power is turned off with the Remote Commander   |
| Status Memory            | RGB SIZE, SHIFT<br>Blanking<br>SECAM ON/OFF<br>CLEAR BLUE ON/OFF<br>Color temperature<br>(9300/6500/3200/Preset)<br>V-SHIFT | Horizontal and vertical frequency<br>Condition of sync signal<br>Input connector | When the MEMORY key is pressed<br>When the power is turned off with the Remote Commander   |
| Registration Memory      | Registration  | Horizontal frequency of the input signal   | When the MEMORY key is pressed<br>When the input connector is switched<br>When the horizontal frequency is changed<br>When the power is turned off with the Remote Commander |
| Color Temperature Memory | W/B Bias and Gain   | Status memory  | When the MEMORY key is pressed<br>When the input connector is switched<br>When the color temperature is changed<br>When the power is turned off with the Remote Commander    |

- One projector has only one memory data each for the baud rate, CRT timer and STATUS ON/OFF.

#### Note

When the adjustment is complete, be sure to press the MEMORY key or turn off the power with the Remote Commander.

## 1-18. FINE ADJUSTMENT OF EACH INPUT SIGNAL

After the registration adjustment is performed with no input source connected and the adjusted data are saved as standard data, next input an external signal and carry out the fine adjustment and other adjustments for each input signal.

### Fine Adjustment of the Video Input Signal

- 1** **Connect the video signal source.**  
Connect to the VIDEO IN jack on the projector or to the PC-1271 switcher connected to the projector.
- 2** **Select the input to be adjusted.**  
Press the INPUT SELECT VIDEO key on the Remote Commander. Or, set the SWITCHER/INDEX select switch to SWITCHER and then from among the number keys from 1 to 8, press a key for a video input source.
- 3** **Press the PAGE key four times.**  
Check that the horizontal frequency of the input signal ("fH") indicates 15.7 kHz.

### Fine registration adjustment

- 1** Press the TEST key to display the hatch pattern.
- 2** If necessary, perform the fine adjustment.
- 3** When the fine adjustment is complete, press the MEMORY key to save the adjusted data. (Do not keep it pressed.) The adjusted value will be saved normally.

### SIZE adjustment

Adjust the size of the picture if it does not fit the screen.

- 1** **Press the RGB SIZE key.**  
The video SIZE can be adjusted with the RGB SIZE key.
- 2** **Adjust with the arrow keys.**
  - ▲: The vertical size is expanded.
  - ▼: The vertical size is reduced.
  - ◀: The horizontal size is expanded.
  - ▶: The horizontal size is reduced.
- 3** **After the adjustment is complete, press the MEMORY key.**  
The adjusted data will be saved.

## Blanking Adjustment

If the displayed picture is bigger than the screen, cut off the excess parts.

**1** Press the **BLKG** key.

**2** Press the **POSITION +/-** key to select the part to be adjusted.  
When the **+** key is pressed, the position will change as follows:  
UPPER → LOWER → LEFT → RIGHT  
When the **-** key is pressed, the position will change in the reverse of the above order.

**3** Adjust with the arrow keys.  
Press the **▲** and **▼** keys to adjust the UPPER and LOWER positions.  
Press the **◀** and **▶** keys to adjust the LEFT and RIGHT positions.

**4** After the adjustment is complete, press the **MEMORY** key.  
The adjusted data will be saved.

### Note

When two or more video input sources are connected to the projector using the switcher, perform the **SIZE** and blanking adjustments for each signal input from different input connector.

## Fine Adjustment of the RGB Input Signal

**1** Connect the **RGB** input source.  
Connect to the **RGB IN** connector on the projector or to the **PC-1271** switcher connected to the projector.

**2** Select the input to be adjusted.  
Press the **INPUT SELECT A** or **B** key on the Remote Commander. Or, set the **SWITCHER/INDEX** select switch to **SWITCHER** and then from among the number keys from 1 to 8, press a key for an RGB input source.

**3** Press the **PAGE** key four times to check the horizontal frequency ("fH") of the input signal.  
If "fH" indicates 30 — 37 kHz (the range of registration memory block 4), the fine adjustment is not necessary.  
For the input signals of other "fH", perform the fine adjustment.

**Fine registration adjustment**

- 1** Press the TEST key to display the hatch pattern.
- 2** If necessary, perform the fine registration adjustment.
- 3** When two or more RGB input sources are connected, group them according to the horizontal frequency by checking the "FH" in PAGE 4 display.
- 4** Perform the fine registration adjustment for each group.  
After the adjustment is complete, press the MEMORY key.  
(Do not keep this key pressed.)  
The adjusted data will be saved.


**Adjustment hint**

The projector saves the registration adjustment data in one of seven (for VPH-1251Q) or eight (for VPH-1271Q) registration memory blocks according to the horizontal frequency of the input signals. When two or more signals are input, you need to perform the fine adjustment for each block. If two or more input signals are grouped into the same memory block, perform the adjustment for any one of them. You can check in which block the signal is grouped by displaying .

**RGB SIZE adjustment**

If the size of the picture does not fit the screen, adjust the RGB SIZE adjustment.

- 1** Press the RGB SIZE key.
- 2** Adjust with the arrow keys so that the picture fits the screen.
  - ▲: The vertical size is expanded.
  - ▼: The vertical size is reduced.
  - ◀: The horizontal size is expanded.
  - ▶: The horizontal size is reduced.



- 3** When the adjustment is complete, press the MEMORY key.  
The adjusted data will be saved.


## RGB SHIFT Adjustment

If the picture needs to be shifted to fit the screen, adjust the RGB SIZE adjustment.

**1** Press the RGB SHIFT key.

**2** Adjust with the arrow keys so that the picture fits the screen.

- ▲: The picture is shifted upward.
- ▼: The picture is shifted downward.
- ◀: The picture is shifted leftward.
- ▶: The picture is shifted rightward.



**3** When the adjustment is complete, press the MEMORY key.  
The adjusted data will be saved.

## Blanking Adjustment

If the displayed picture is bigger than the screen, cut off the excess parts.

**1** Press the BLKG key.

**2** Press the POSITION +/- key to select the part to be adjusted.  
When the + key is pressed, the position will change as follows:  
UPPER → LOWER → LEFT → RIGHT  
When the - key is pressed, the position will change in the reverse of the above order.

**3** Adjust with the arrow keys.  
Press the ▲ and ▼ keys to adjust the UPPER and LOWER positions.  
Press the ◀ and ▶ keys to adjust the LEFT and RIGHT positions.

**4** When the adjustment is complete, press the MEMORY key.  
The adjusted data will be saved.

### Note

When two or more RGB input sources are connected to the projector, perform the size, shift and blanking adjustments for each RGB signal which has any item different from each other in the signal input conditions displayed in PAGE 4.

## White Balance Adjustment

The color temperatures are preset at the factory to 9300K, 6500K and 3200K. However, if you want to set a color temperature other than the factory-preset levels, you can adjust the white balance and save it in the memory. You can also change the factory-preset levels.

### Setting the white balance

- 1** Display the same input signal on the projector and the color monitor.
- 2** Press the PAGE key three times to display PAGE 3.
 

```

PAGE 3          INPUT-A
SYSTEM PRESET
COLOR TEMPERATURE:
9300-6500-3200 PRESET
CLAMP: AUTO SonG H/C H.P
V-SHIFT: WIDE  NARROW


SELECT:   
NEXT: [PAGE]

```
- 3** Press the arrow keys to select 9300, 6500 or 3200, the nearest color temperature to that of the color monitor or the desired one.  
Normally set to 6500. Set to 9300 to make white color bluish and select 3200 to make it reddish.
- 4** Press the MEMORY key.

### Adjusting the white balance

If you want to make the color of a particular input signal (ex. HDTV system picture) uniform to that of the color monitor, you can adjust the white balance. Display the same input signal on the projector and the monitor.

- 1** Press the PAGE key three times to display PAGE 3.
- 2** Set COLOR TEMPERATURE to PRESET with the arrow keys.



- 3** Set the contrast and the brightness of the color monitor to the standard levels.
- 4** Adjust the black level.
  - ①** Press the W/B BIAS key.  
The PLUGE pattern is displayed.  
The contrast and the brightness levels of the projector are automatically set to 80 and 50 respectively.
  - ②** Keep pressing the TEST key for more than 5 seconds.  
The picture of the input signal is displayed.
  - ③** Press the ADJ R, G or B key to select the color to be adjusted.  
In selecting the color, pay attention to the black part of the picture displayed on the projector screen and note which color stands out compared with the same part displayed on the color monitor.
  - ④** Press the ◀ or ▶ key so that the black color of the picture on the projector looks the same as that on the monitor.  
If the brightness of that part does not look the same as that on the monitor, adjust other colors by pressing the ADJ R, G or B key and arrow keys.
  - ⑤** Press the MEMORY key.  
The adjusted data is saved.

## 5 Adjust the white level.

- ① **Press the W/B GAIN key.**  
The window pattern is displayed.  
The contrast and the brightness levels of the projector are automatically set to 80 and 50, respectively.
- ② **Keep pressing the TEST key for more than 5 seconds.**  
The picture of the input signal is displayed.
- ③ **Press the ADJ R, G or B key to select the color to be adjusted.**  
In selecting the color, pay attention to the white part of the picture displayed on the projector screen and note which color stands out compared with the same part displayed on the color monitor.
- ④ **Press the ◀ or ▶ key so that the white part of the picture on the projector screen looks the same as that on the monitor.**  
If the brightness of that part does not look the same as that on the monitor, adjust other colors by pressing the ADJ R, G or B key and the arrow keys.
- ⑤ **Press the MEMORY key.**  
The adjusted data is saved.

### When multiple projectors are used

Input the same signal to the based projector and the projector to be adjusted.  
Set COLOR TEMPERATURE on PAGE 3 to the same position on both projectors and then follow steps 4 and 5 in the above procedures to make the black and white colors uniform between the based projector and the other.

### Note

You can adjust more easily if you set the COLOR level to MIN to display the black and white picture.


## If the Luminance of the Picture is Incorrect — Clamp Setting

Clamp is used as a standard for setting the black level of the picture correctly. The standard position of the clamp depends on the kind of the sync signal. Normally the CPU may judge the signal and sets the clamp position automatically.

However, the CPU may misjudge the signal because of noise. If the luminance of the picture seems to be incorrect (too dark, the black color is too light, or the luminance is unstable), the clamp position may need to be changed.

In such case, change the clamp position following the procedure below.

- 1 Press the PAGE key 3 times.



- 2 Select the clamp position by pressing ◀, ▶, ▲ and ▼ keys.

**AUTO** : Automatic setting mode. Normally, set to this position.

**S on G** : If the black color is too light or seems to be green, set to this position.

**H/C** : If the picture is too dark or the luminance is unstable, set to this position.

**H.P** : If the luminance is still incorrect after changing the clamp setting to "S on G" or "H/C", set to this position and perform H-SHIFT adjustment.

- 3 Press the MEMORY key to save the data.

### If the luminance is still incorrect after changing the clamp setting

There may be other problems with the input signal or connection. Check the input signal.

## 1-19. DATA RESET

There are two possibilities for data reset, the data reset and factory reset.

**Previous data reset**

The data are reset to the previously saved data (the data before the adjustment).


**Factory reset**

The data are reset to the factory preset level. The factory reset can be performed after the previous data reset.

### How to Reset the Data

**1** Select the adjustment mode to be reset.


**2** Press the ◀ and ▶ keys simultaneously. The following display appears.



\* Check that "previously" is displayed here.


(ex. To reset the red size adjustment data to the previously saved data)

**3** Press the ▲ key.



The data will be reset to the previously saved data. (Previous data reset)

**4** Press the ◀ and ▶ keys simultaneously again. The following display appears.



\* Check that "factory" is displayed here.

(ex. To reset the red size adjustment data to the factory preset level)

**5** Press the ▲ key. The data will be reset to the factory preset level. (Factory reset)

# Resetting the Registration Standard Data to the Factory Preset Levels

If the registration data were adjusted and saved, you need reset the data to the factory preset levels before starting the registration adjustment.

|  |  |
|--|--|
| <b>1</b> Press the <b>CENT R</b> and <b>B</b> keys simultaneously to enter the green centering adjustment mode.  | <b>5</b> Press the <b>ADJ R</b> key and then perform the factory reset operation.<br>The <b>SIZE</b> , <b>LIN</b> , <b>SKEW</b> , <b>BOW</b> , <b>KEY</b> , <b>PIN</b> and <b>ZONE</b> adjustment data are reset to the factory preset levels. |
| <b>2</b> Follow steps 2 to 5 on page 103.<br>The centering adjustment data of the red, green and blue signals are reset to the factory preset levels.  | <b>6</b> Press the <b>ADJ B</b> key and then perform the factory reset operation.<br>The <b>SIZE</b> , <b>LIN</b> , <b>SKEW</b> , <b>BOW</b> , <b>KEY</b> , <b>PIN</b> and <b>ZONE</b> adjustment data are reset to the factory preset levels. |
| <b>3</b> Press the <b>SIZE</b> key.  | <b>7</b> Press the <b>BLKG</b> key.  |
| <b>4</b> Press the <b>ADJ G</b> key and then perform the factory reset operation.<br>The <b>SIZE</b> , <b>LIN</b> , <b>SKEW</b> , <b>BOW</b> , <b>KEY</b> , <b>PIN</b> and <b>ZONE</b> adjustment data are reset to the factory preset levels. | <b>8</b> Press the <b>TEST</b> key and then perform the factory reset operation.<br>The <b>UPPER</b> , <b>LOWER</b> , <b>LEFT</b> and <b>RIGHT</b> blanking adjustment data are reset.   |

**The resetting of the standard data to the factory preset levels is complete. Then start the registration adjustment.**

**For reference — Mode and data reset correspondence**

| Mode   | Data to be reset  |
|--|---|
| RGB Size   | H-size and V-size   |
| RGB Shift  | H-shift and V-shift   |
| G-centering  | Centering data for all colors   |
| R-centering  | Not applicable  |
| B-centering  | Not applicable  |
| Size, Linearity<br>Skew, Bow<br>Keystone<br>Pincushion | All the registration data for the selected color (including the Zone data)    |
| Zone   | Zone data for the selected color is set to the middle adjustment level (128). |
| Blanking   | UPPER/LOWER/LEFT/RIGHT side blanking data                                     |
| Gain, Bias   | All the Bias and Gain data for all colors at the current color temperature    |

**ZONE data reset**


The ZONE data reset allows to set the ZONE data of all the positions to 128, middle adjustment level. Perform the ZONE data reset if wavelike distortion occurs with the outermost line of the hatch pattern or the red and blue lines do not converge when adjusting registration (only when the projector is not installed on the floor using the 120-inch front type screen). After the ZONE data reset, start with the KEY and PIN adjustments and then perform the ZONE adjustment again.

**1-20. TO ACTIVATE THE PROTECTION ON THE REMOTE COMMANDER**

When you turn off the projector with the Remote Commander, the adjustment keys become inoperable in order to prevent the users from changing the registration adjustments.

It is also possible to make the keys inoperable while the power is on in the following way.

- 1** Keep pressing the **NORMAL** key for at least 3 seconds.



- 2** Press the **▲** key.  
The adjustment keys are now inoperable.


## 1-21. PICTURE ADJUSTMENT

Adjust the picture for your preference. The adjusted data can be saved in the memory.

### 1 Adjust with the PICTURE CONTROL +/- keys.

|              |                  |
|--------------|------------------|
| <b>CONTR</b> | picture contrast |
| <b>COLOR</b> | color intensity  |
| <b>BRT</b>   | brightness       |
| <b>SHARP</b> | sharpness        |
| <b>HUE</b>   | hue              |


The adjustment levels are digitally displayed having a range of MIN, 1, 2 ... 99, Max.



### 2 When the adjustment is complete, press the MEMORY key.

## To restore the factory preset levels

Press the RESET key.  
The factory preset levels are displayed on the screen.



### Notes

- The COLOR, SHARP and HUE keys do not function on the pictures input from the RGB IN connectors.
- The HUE and COLOR keys do not function if the input signal is black and white.
- The HUE key does not function with the PAL or SECAM color source.

### Dynamic picture mode (only for the video input pictures)

You can obtain the picture of high quality contrast by setting the DYNAMIC PIC SW to ON inside the projector. See "Dynamic picture setting".


1-22. VARIOUS SETTINGS

## Changing the Initialization Time


You can set the period of initializing when the projector warms up to the desired minutes in intervals of 1 minute.

**1** Set the Remote Commander to the serviceman adjustment mode.

**2** Keep pressing the **POWER ON** key on the Commander for 5 seconds.  
The following display appears.



**3** Press the **▶** and **◀** keys to set to the desired minutes.  
▶: to increase by 1 minute  
◀: to decrease by 1 minute



**4** Press the **▲** key.  
The display disappears.

**To cancel the setting**


Press the **▼** key instead of the **▲** key in step 4.

**To set so that the signal input from the connected equipment is displayed on the screen immediately after the power is turned on.**

Set to 0 min.

### 1-23. LIST OF THE MESSAGES

Use the list below to check the meaning of the messages displayed on the screen.  
The list is divided into sections depending on the location which the message appears. Check the location first, then refer to the alphabet for the section to find the message.



(D), (F), (G), (K), (L) and a part of (I) will appear all over the screen.

|   |  |
|---|--|
| <b>A Caution, Message</b>   |  |
| <ul style="list-style-type: none"> <li>•Not applicable!</li> <li>•Overflow!</li> <li>•PIC MUTE</li> <li>•Input is not VIDEO.</li> <li>•Input is not NTSC.</li> <li>•Input is not RGB.</li> <li>•Input is B &amp; W.</li> <li>•NO INPUT</li> </ul> | <ul style="list-style-type: none"> <li>•The key is not applicable in the current mode.</li> <li>•The adjustment data has passed the adjustable range limit, and does not change any more.</li> <li>•Picture mute mode is on.</li> <li>•The input signal is not VIDEO.</li> <li>•The input signal is not NTSC.</li> <li>•The input signal is not RGB.</li> <li>•The input signal is black and white.</li> <li>•No signal is input.</li> </ul> |
| <b>B PIC CONTROL data</b>   |  |
| <ul style="list-style-type: none"> <li>•CONTR (CONTRAST)</li> <li>•COLOR</li> <li>•BRT (BRIGHTNESS)</li> <li>•SHARP (SHARPNESS)</li> <li>•HUE</li> <li>•PIC CONTROL data reset</li> </ul>   | <ul style="list-style-type: none"> <li>•Contrast</li> <li>•Color</li> <li>•Brightness</li> <li>•Sharpness</li> <li>•Hue</li> <li>•Resets the PIC CONTROL data.</li> </ul>  |
| <b>C Input channel</b>  |  |
| <ul style="list-style-type: none"> <li>•VIDEO</li> <li>•INPUT-A</li> <li>•INPUT-B</li> <li>•SW'ER x-y (switcher x = 1-2, y = 1-8)</li> <li>•POSITION No. x (VPH-1251Q: x = 1-9, VPH-1271Q: x = 1-21)</li> </ul>                                   | <ul style="list-style-type: none"> <li>•Input from VIDEO IN</li> <li>•Input from optional interface board</li> <li>•Input from RGB IN</li> <li>•Input from optional switcher</li> <li>•The cursor position in ZONE adjustment</li> </ul>   |

|  |  |
|--|--|
| <b>D PAGE</b>  |  |
| <p>Subtitle</p> <ul style="list-style-type: none"> <li>•USER PRESET</li> <li>•USER CONTROL</li> <li>•SYSTEM PRESET</li> <li>•INPUT INFO (INPUT INFORMATION)</li> <li>•OTHER ITEMS</li> </ul> <p>PAGE 1</p> <ul style="list-style-type: none"> <li>•STATUS ON/OFF</li> <li>•PIC MUTE ON/OFF</li> <li>•AUDIO MUTE ON/OFF</li> <li>•CLEAR BLUE ON/OFF/ ---</li> <li>•SECAM ON/OFF/ ---</li> </ul> <p>PAGE 2</p> <ul style="list-style-type: none"> <li>•CONTR (CONTRAST)</li> <li>•COLOR</li> <li>•BRT (BRIGHTNESS)</li> <li>•SHARP (SHARPNESS)</li> <li>•VOL</li> <li>•HUE</li> <li>•PIC CONTROL data reset</li> </ul> <p>PAGE 3</p> <ul style="list-style-type: none"> <li>•COLOR TEMPERATURE: 9300/6500/3200/ PRESET</li> <li>•CLAMP: AUTO / S on G/ H/C / H.P.</li> <li>•V-SHIFT: WIDE NARROW</li> </ul> <p>PAGE 4</p> <ul style="list-style-type: none"> <li>•INPUT SIGNAL</li> <li>•Y/C</li> <li>•RGB</li> <li>•NTSC</li> <li>•PAL</li> </ul> | <ul style="list-style-type: none"> <li>•User preset</li> <li>•User control</li> <li>•System preset</li> <li>•Input information</li> <li>•Other items</li> <li>•On-screen display on/off</li> <li>•Picture mute mode on/off</li> <li>•Audio mute mode on/off</li> <li>•Clear blue mode on/off/does not function.</li> <li>•Compulsive SECAM mode on/off/does not function.</li> <li>•Contrast</li> <li>•Color</li> <li>•Brightness</li> <li>•Sharpness</li> <li>•Volume</li> <li>•Hue</li> <li>•Resets the PIC CONTROL data.</li> <li>•Color temperature is set to 9300/6500/3200/ the data adjustable by the service personnel.</li> <li>•Clamp position is set to automatic/internal/ external sync signal/ horizontal deflection pulse position.</li> <li>•The adjustable range of vertical shift is wide/narrow.</li> <li>•Input signal</li> <li>•S video input signal from VIDEO IN</li> <li>•RGB input signal</li> <li>•NTSC input signal from VIDEO IN</li> <li>•PAL input signal from VIDEO IN</li> </ul> |

|  |  |
|--|--|
| <ul style="list-style-type: none"> <li>•SECAM</li> <li>•B &amp; W</li> <li>•f<sub>H</sub></li> <li>•f<sub>V</sub></li> <li>•Internal oscillation</li> <li>•H/C-SYNC</li> <li>•V-SYNC</li> <li>•SYNC ON G</li> <li>•H/C-SYNC:<br/>POS/NEG/ ---</li> <li>•V-SYNC:<br/>POS/NEG/ ---</li> <li>•SYNC ON G:<br/>NEG/ ---</li> <li>•REGI BLOCK: No. x</li> </ul> <p>PAGE 5</p> <ul style="list-style-type: none"> <li>•1. CRT TIMER DISPLAY</li> <li>•2. BAUD RATE PRESET</li> </ul> <p>PAGE 5-1</p> <ul style="list-style-type: none"> <li>•CRT TIMER DISPLAY MODE</li> <li>RED: xxxx hours</li> <li>GREEN: xxxx hours</li> <li>BLUE: xxxx hours</li> <li>•CRT TIMER RESET MODE</li> <li>RED: xxxx hours</li> <li>GREEN: xxxx hours</li> <li>BLUE: xxxx hours</li> </ul> <p>PAGE 5-2</p> <ul style="list-style-type: none"> <li>•RS422 COMMUNICATION BAUD RATE PRESET MODE</li> <li>38.4K/19.2K/9600/4800</li> </ul> | <ul style="list-style-type: none"> <li>•SECAM input signal from VIDEO IN</li> <li>•Black and white input signal from VIDEO IN</li> <li>•Horizontal frequency</li> <li>•Vertical frequency</li> <li>•Internal oscillation mode (No signal is input.)</li> <li>•Horizontal sync signal or composite sync signal</li> <li>•Vertical sync signal</li> <li>•Composite video signal</li> <li>•The polarity of the H/C-SYNC is positive/negative/not input.</li> <li>•The polarity of the V-SYNC is positive/negative/not input.</li> <li>•The polarity of the SYNC ON G is negative/not input.</li> <li>•The input signal is grouped into the registration memory block No. x.</li> </ul> <ul style="list-style-type: none"> <li>•CRT use time display</li> <li>•Baud rate setting display</li> </ul> <ul style="list-style-type: none"> <li>•CRT use time display mode</li> <li>•Red CRT use time: xxxx hours</li> <li>•Green CRT use time: xxxx hours</li> <li>•Blue CRT use time: xxxx hours</li> <li>•CRT use time reset mode</li> <li>•Red CRT use time: xxxx hours</li> <li>•Green CRT use time: xxxx hours</li> <li>•Blue CRT use time: xxxx hours</li> </ul> <ul style="list-style-type: none"> <li>•The baud rate is set to 38.4K/19.2K/9600/4800 when communicating via the RS-422.</li> </ul> |
| <p><b>E Operation</b></p> <ul style="list-style-type: none"> <li>•YES: ▲</li> <li>•NO: ▼</li> <li>•SELECT: ◀▶</li> <li>•SELECT: ◀▶▲▼</li> <li>•ADJ: ◀▶▲▼</li> <li>•ADJ: ◀▶</li> <li>•ADJ: ▲▼</li> </ul>  |  |
| <ul style="list-style-type: none"> <li>•Press ▲ key for "Yes".</li> <li>•Press ▼ key for "No".</li> <li>•Press ◀ or ▶ key to select.</li> <li>•Press, ◀, ▶, ▲ or ▼ key to select.</li> <li>•Press ◀, ▶, ▲ or ▼ key to adjust.</li> <li>•Press ◀ or ▶ key to adjust.</li> <li>•Press ▲ or ▼ key to adjust.</li> </ul>   |  |

|  |   |
|--|---|
| <ul style="list-style-type: none"> <li>•NEXT: [+][-]</li> <li>•NEXT: [PAGE]</li> <li>•EXIT: [PAGE]</li> <li>•EXIT: [NORMAL]</li> <li>•ENTER: ▶</li> <li>•TIMER RESET MODE<br/>◀▶ simultaneously</li> <li>•COLOR SELECT: ▲▼</li> <li>•TIMER RESET: ◀</li> <li>•ENTER: [MEMORY]</li> </ul>   | <ul style="list-style-type: none"> <li>•Press [+ key to move the cursor to the next position.</li> <li>•Press [- key to move the cursor to the previous position.</li> <li>•Press PAGE key to go to the next page.</li> <li>•Press PAGE key to exit the PAGE mode.</li> <li>•Press NORMAL key to exit the TEST mode.</li> <li>•Press ▶ key to execute the selected item.</li> <li>•Press ◀ and ▶ keys simultaneously to enter the CRT use time reset mode.</li> <li>•Press ▲ or ▼ key to select color.</li> <li>•Press ◀ key to set the CRT use time to 0000.</li> <li>•Press MEMORY key to save the reset conditions.</li> </ul> |
| <p><b>F Memory data</b></p> <ul style="list-style-type: none"> <li>•MEMORY DATA in saving.</li> <li>•MEMORY DATA saving is complete!</li> <li>•No key may be applicable during the indication of this mode.</li> <li>•The registration data will be used as standard for all inputs OK?</li> </ul>   |   |
| <ul style="list-style-type: none"> <li>•Saving the memory data now.</li> <li>•Saving the memory data is completed.</li> <li>•When in this mode (MEMORY DATA saving), no key functions.</li> <li>•Is it all right that this registration data will be used as standard for all inputs?</li> </ul>   |   |
| <p><b>G Data reset</b></p> <ul style="list-style-type: none"> <li>•Do you wish to return to factory preset data?</li> <li>•Do you wish to return to previously saved data?</li> <li>•Reset complete!</li> <li>•RGB SIZE DATA RESET MODE</li> <li>•RGB SHIFT DATA RESET MODE</li> <li>•BLANKING DATA RESET MODE</li> <li>•CENTERING ALL COLOR DATA RESET MODE</li> <li>•W/B GAIN &amp; BIAS ALL COLOR DATA RESET MODE</li> <li>•REGISTRATION (RED/GREEN/BLUE) DATA RESET MODE</li> </ul>  |   |
| <ul style="list-style-type: none"> <li>•Do you wish to reset the data to the factory preset data?</li> <li>•Do you wish to reset the data to the previously saved data?</li> <li>•Resetting is completed.</li> <li>•RGB or video input size data resetting mode</li> <li>•RGB input shift data resetting mode</li> <li>•Blanking data resetting mode</li> <li>•Centering data (all color) resetting mode</li> <li>•Gain, bias (all color) data resetting mode</li> <li>•Registration (red, green or blue) data resetting mode</li> </ul> |   |

|   |  |
|---|--|
| <b>H Raster</b>   |  |
| <ul style="list-style-type: none"> <li>•RASTER R G B</li> <li>•RASTER R - -</li> <li>•RASTER - G -</li> <li>•RASTER - - B</li> <li>•RASTER R G -</li> <li>•RASTER R - B</li> <li>•RASTER - G B</li> </ul> | <ul style="list-style-type: none"> <li>•Red, green and blue are projected.</li> <li>•Only red is projected.</li> <li>•Only green is projected.</li> <li>•Only blue is projected.</li> <li>•Red and green are projected.</li> <li>•Red and blue are projected.</li> <li>•Green and blue are projected.</li> </ul> |

|   |   |
|---|---|
| <b>I Adjustment</b>   |   |
| <ul style="list-style-type: none"> <li>•RGB SIZE ADJ</li> <li>•RGB SHIFT ADJ</li> <li>•R CENT ADJ</li> <li>•G CENT ADJ</li> <li>•B CENT ADJ</li> <li>•SIZE ADJ</li> <li>•fine</li> <li>•LIN (LINEARITY) ADJ</li> <li>•SKEW ADJ</li> <li>•BOW ADJ</li> <li>•KEY (KEYSTONE) ADJ</li> <li>•PIN (PINCUSHION) ADJ</li> <li>•ZONE ADJ</li> <li>•BLKG ADJ UPPER/<br/>LOWER/LEFT/RIGHT</li> <li>•BIAS ADJ</li> <li>•GAIN ADJ</li> </ul> | <ul style="list-style-type: none"> <li>•RGB or video input size adjustment mode</li> <li>•RGB input shift adjustment mode</li> <li>•Red centering adjustment mode</li> <li>•Green centering adjustment mode</li> <li>•Blue centering adjustment mode</li> <li>•Size adjustment mode</li> <li>•Picture size fine-adjustment mode for green.</li> <li>•Linearity adjustment mode</li> <li>•Skew adjustment mode</li> <li>•Bow adjustment mode</li> <li>•Keystone adjustment mode</li> <li>•Pincushion adjustment mode</li> <li>•Zone adjustment mode</li> <li>•Blanking adjustment (upper, lower, left, or right) mode</li> <li>•White balance bias adjustment mode</li> <li>•White balance gain adjustment mode</li> </ul> |


|  |  |
|--|--|
| <b>J Adjustment data</b>   |  |
| <ul style="list-style-type: none"> <li>•H: xxx</li> <li>•V: xxx</li> <li>•Hf: xxx</li> <li>•Hc: xxx</li> <li>•Vf: xxx</li> <li>•Vc: xxx</li> </ul> | <ul style="list-style-type: none"> <li>•Horizontal adjustment level (xxx = 0-255)</li> <li>•Vertical adjustment level (xxx = 0-255)</li> <li>•Centering adjustment level for horizontal direction (xxx = 0-255)<br/>The level changes with the arrow keys pressed once.</li> <li>•Centering adjustment level for horizontal direction (xxx = 0-255)<br/>The level changes with the arrow keys kept pressed.</li> <li>•Centering adjustment level for vertical direction (xxx = 0-255)<br/>The level changes with the arrow keys pressed once.</li> <li>•Centering adjustment level for vertical direction (xxx = 0-255)<br/>The level changes with the arrow keys kept pressed.</li> </ul> |

|   |   |
|---|---|
| <b>K Caution, Message (VPH-1251QM only)</b>   |   |
| <ul style="list-style-type: none"> <li>•fH is too high!<br/>This input signal cannot be projected as the horizontal frequency is too high.</li> </ul> | <ul style="list-style-type: none"> <li>•The horizontal frequency is too high. This input signal cannot be projected as the horizontal frequency exceeds the acceptable level of the projector.</li> </ul> |

|  |  |
|--|--|
| <b>L Others</b>  |  |
| <ul style="list-style-type: none"> <li>•For optimum performance, white screen will remain for 20 min.<br/>For immediate use, push [PAGE] key.</li> <li>•INITIALIZATION TIME SETTING</li> <li>•You can change the white screen display time.<br/>Standard 20 min ... xx min</li> <li>•Do you wish to enter into the SERVICEMAN CONTROL MODE?</li> <li>•Do you wish to return to the USER CONTROL MODE?</li> </ul> | <ul style="list-style-type: none"> <li>•For optimum performance, white screen will remain for 20 min.<br/>For immediate use, push PAGE key.</li> <li>•Initialization time setting mode.</li> <li>•You can change the white screen display time.<br/>The factory preset time is 20 min. The current preset time is xx min.</li> <li>•Do you wish to enter into the service-personnel control mode?</li> <li>•Do you wish to return to the user control mode?</li> </ul> |

## About the Error Codes

When an operational error occurs, the power will automatically turn off and the error code will light up on the error code window on the side panel. Refer to the chart below for the meanings.



Error code window  
(Inside of cabinet)


### Y: Error occurrence

| Code \ error | FAN stop | (H stop)<br>100V down | IK-over | V-stop | HV-over | power-down |
|--------------|----------|-----------------------|---------|--------|---------|------------|
| 01 .....     | Y        | —                     | —       | —      | —       | —          |
| 02 .....     | —        | Y                     | —       | —      | —       | —          |
| 03 .....     | Y        | Y                     | —       | —      | —       | —          |
| 04 .....     | —        | —                     | Y       | —      | —       | —          |
| 05 .....     | Y        | —                     | Y       | —      | —       | —          |
| 06 .....     | —        | Y                     | Y       | —      | —       | —          |
| 07 .....     | Y        | Y                     | Y       | —      | —       | —          |
| 08 .....     | —        | —                     | —       | Y      | —       | —          |
| 09 .....     | Y        | —                     | —       | Y      | —       | —          |
| 0A .....     | —        | Y                     | —       | Y      | —       | —          |
| 0b .....     | Y        | Y                     | —       | Y      | —       | —          |
| 0C .....     | —        | —                     | Y       | Y      | —       | —          |
| 0d .....     | Y        | —                     | Y       | Y      | —       | —          |
| 0E .....     | —        | Y                     | Y       | Y      | —       | —          |
| 0_ .....     | Y        | Y                     | Y       | Y      | —       | —          |
| 10 .....     | —        | —                     | —       | —      | Y       | —          |
| 11 .....     | Y        | —                     | —       | —      | Y       | —          |
| 12 .....     | —        | Y                     | —       | —      | Y       | —          |
| 13 .....     | Y        | Y                     | —       | —      | Y       | —          |
| 14 .....     | —        | —                     | Y       | —      | Y       | —          |
| 15 .....     | Y        | —                     | Y       | —      | Y       | —          |
| 16 .....     | —        | Y                     | Y       | —      | Y       | —          |
| 17 .....     | Y        | Y                     | Y       | —      | Y       | —          |
| 18 .....     | —        | —                     | —       | Y      | Y       | —          |
| 19 .....     | Y        | —                     | —       | Y      | Y       | —          |
| 1A .....     | —        | Y                     | —       | Y      | Y       | —          |
| 1b .....     | Y        | Y                     | —       | Y      | Y       | —          |
| 1C .....     | —        | —                     | Y       | Y      | Y       | —          |
| 1d .....     | Y        | —                     | Y       | Y      | Y       | —          |
| 1E .....     | —        | Y                     | Y       | Y      | Y       | —          |
| 1_ .....     | Y        | Y                     | Y       | Y      | Y       | —          |
| 20 .....     | —        | —                     | —       | —      | —       | Y          |

### Notes

- When the error code lights up, all the previous adjustment data will be cleared.
- The error code will disappear when the MAIN POWER switch is turned off and the power cord is disconnected.
- The error code will light up every time the power is turned on unless the operational error is recovered to normal.

1-24. LIST OF WASHERS USED FOR NON-STANDARD INSTALLATION




| Angle of optical axis (°) | Screen size (inches) |   | 70      | 72      | 75      | 80      | 85      | 86      | 90      | 95      | 100     | 105     | 110     | 115     |         |
|---------------------------|----------------------|---|---------|---------|---------|---------|---------|---------|---------|---------|---------|---------|---------|---------|---------|
|                           | B'                   | E |         |         |         |         |         |         |         |         |         |         |         |         |         |
| 1                         | 0.0087 – 0.0262      | A | 1+1.2   | 1+1.2   | 1+1.2   | 1+1.2   | 1+1.2   | 1+0.5   | 1+0.5   | 1+0.5   | 1+0.5   | 1+0.5   | 1+0.5   | 1+0.5   | 1+0.5   |
|                           |                      | B | 60      | 60      | 60      | 65      | 70      | 70      | 75      | 80      | 80      | 85      | 90      | 95      | 95      |
| 2                         | 0.0263 – 0.0437      | A | 1+1     | 1+1     | 1+1     | 1+1     | 1+1     | 1.2     | 1.2     | 1+0.4   | 1+0.4   | 1+0.4   | 1+0.4   | 1+0.4   | 1+0.4   |
|                           |                      | B | 50      | 60      | 60      | 65      | 70      | 70      | 75      | 80      | 80      | 85      | 90      | 95      | 95      |
| 3                         | 0.0438 – 0.0612      | A | 1.2+0.5 | 1.2+0.5 | 1.2+0.5 | 1.2+0.5 | 1.2+0.5 | 1.2     | 1.2     | 1.2     | 1.2     | 1.2     | 1.2     | 1.2     | 1.2     |
|                           |                      | B | 55      | 55      | 60      | 65      | 70      | 70      | 70      | 75      | 80      | 85      | 90      | 95      | 95      |
| 4                         | 0.0613 – 0.0787      | A | 1.2+0.4 | 1.2+0.5 | 1.2+0.5 | 1.2+0.5 | 1.2+0.5 | 1.0     | 1.0     | 1.0     | 1.0     | 1.0     | 1.0     | 1.0     | 1.0     |
|                           |                      | B | 55      | 55      | 60      | 65      | 70      | 70      | 70      | 75      | 80      | 85      | 90      | 90      | 90      |
| 5                         | 0.0788 – 0.0963      | A | 1+0.5   | 1+0.5   | 1+0.5   | 1.2+0.4 | 1.2+0.4 | 0.4+0.5 | 0.4+0.5 | 0.4+0.5 | 1.0     | 1.0     | 1.0     | 1.0     | 1.0     |
|                           |                      | B | 55      | 55      | 60      | 65      | 70      | 70      | 70      | 75      | 80      | 85      | 90      | 90      | 90      |
| 6                         | 0.0964 – 0.1139      | A | 1.2     | 1.2     | 1.2     | 1+0.4   | 1+0.4   | 0.5     | 0.4+0.4 | 0.4+0.4 | 0.4+0.4 | 0.4+0.5 | 0.4+0.5 | 0.4+0.5 | 0.4+0.5 |
|                           |                      | B | 50      | 50      | 55      | 60      | 65      | 60      | 65      | 65      | 70      | 75      | 80      | 80      | 80      |
| 7                         | 0.1140 – 0.1317      | A | 1.0     | 1.0     | 1.2     | 1.2     | 1.2     | 0.5     | 0.5     | 0.5     | 0.5     | 0.4+0.4 | 0.4+0.4 | 0.4+0.4 | 0.4+0.4 |
|                           |                      | B | 45      | 45      | 50      | 50      | 55      | 55      | 55      | 55      | 60      | 60      | 65      | 70      | 70      |
| 8                         | 0.1318 – 0.1495      | A | 0.4+0.5 | 1.0     | 1.0     | 1.0     | 1.2     | 0.5     | 0.5     | 0.5     | 0.5     | 0.5     | 0.5     | 0.5     | 0.5     |
|                           |                      | B | 40      | 40      | 40      | 45      | 50      | 45      | 45      | 45      | 50      | 50      | 55      | 60      | 60      |
| 9                         | 0.1496 – 0.1673      | A | 0.4+0.4 | 0.4+0.4 | 0.4+0.5 | 1.0     | 1.0     | 0.4     | 0.4     | 0.4     | 0.5     | 0.5     | 0.5     | 0.5     | 0.5     |
|                           |                      | B | 35      | 35      | 35      | 40      | 40      | 35      | 40      | 40      | 45      | 45      | 50      | 50      | 50      |
| 10                        | 0.1674 – 0.1853      | A | 0.5     | 0.5     | 0.5     | 0.4+0.4 | 0.4+0.5 | —       | —       | 0.4     | 0.4     | 0.4     | 0.5     | 0.5     | 0.5     |
|                           |                      | B | 25      | 30      | 30      | 30      | 35      | 30      | 30      | 35      | 35      | 40      | 40      | 40      | 40      |
| 11                        | 0.1854 – 0.2035      | A | 0.4     | 0.5     | 0.5     | 0.5     | 0.4+0.4 | —       | —       | —       | —       | 0.4     | 0.4     | 0.4     | 0.4     |
|                           |                      | B | 20      | 20      | 25      | 25      | 25      | 20      | 25      | 25      | 25      | 30      | 30      | 30      | 30      |
| 12                        | 0.2036 – 0.2217      | A | —       | 0.4     | 0.4     | 0.5     | 0.5     | —       | —       | —       | —       | —       | —       | —       | 0.4     |
|                           |                      | B | 15      | 15      | 15      | 20      | 20      | 14      | 14      | 15      | 20      | 20      | 20      | 20      | 20      |
| 13                        | 0.2218 – 0.2401      | A | —       | —       | —       | 0.4     | 0.5     | —       | —       | —       | —       | —       | —       | —       | —       |
|                           |                      | B | 10      | 10      | 10      | 10      | 10      | 5       | 5       | 5       | 10      | 10      | 10      | 10      | 10      |
| 14                        | 0.2402 – 0.2493      | A | —       | —       | —       | —       | 0.4     | 0.4     | —       | —       | —       | —       | —       | —       | —       |
|                           |                      | B | 5       | 5       | 5       | 5       | 5       | 0       | 0       | 0       | 0       | 0       | 0       | 0       | 0       |

| Angle of optical axis (°) | Screen size (inches) |   | 120     | 125     | 130     | 135     | 139     | 140     | 150     | 160     | 170     | 180     | 190     | 200     |
|---------------------------|----------------------|---|---------|---------|---------|---------|---------|---------|---------|---------|---------|---------|---------|---------|
|                           | B'                   | E |         |         |         |         |         |         |         |         |         |         |         |         |
| 1                         | 0.0087 – 0.0262      | A | 1+0.5   | 1+0.5   | 1+0.5   | 1+0.5   | 1+0.5   | 0.4+0.4 | 0.4+0.4 | 0.4+0.4 | 0.4+0.4 | 0.4+0.4 | 0.4+0.4 | 0.4+0.4 |
|                           |                      | B | 100     | 105     | 110     | 110     | 115     | 115     | 120     | 130     | 140     | 150     | 155     | 165     |
| 2                         | 0.0263 – 0.0437      | A | 1+0.4   | 1+0.4   | 1+0.4   | 1+0.4   | 1+0.4   | 0.5     | 0.4+0.4 | 0.4+0.4 | 0.4+0.4 | 0.4+0.4 | 0.4+0.4 | 0.4+0.4 |
|                           |                      | B | 100     | 105     | 105     | 110     | 115     | 115     | 120     | 130     | 140     | 150     | 155     | 165     |
| 3                         | 0.0438 – 0.0612      | A | 1.2     | 1.2     | 1.2     | 1.2     | 1.2     | 0.5     | 0.5     | 0.5     | 0.5     | 0.5     | 0.5     | 0.5     |
|                           |                      | B | 95      | 100     | 105     | 110     | 115     | 110     | 120     | 130     | 135     | 145     | 155     | 160     |
| 4                         | 0.0613 – 0.0787      | A | 1.2     | 1.2     | 1.2     | 1.2     | 1.2     | 0.5     | 0.5     | 0.5     | 0.5     | 0.5     | 0.5     | 0.5     |
|                           |                      | B | 95      | 100     | 105     | 110     | 110     | 110     | 120     | 130     | 135     | 145     | 155     | 160     |
| 5                         | 0.0788 – 0.0963      | A | 1.0     | 1.0     | 1.0     | 1.0     | 1.0     | 0.5     | 0.5     | 0.5     | 0.5     | 0.5     | 0.5     | 0.5     |
|                           |                      | B | 95      | 100     | 105     | 110     | 115     | 110     | 115     | 125     | 130     | 140     | 150     | 155     |
| 6                         | 0.0964 – 0.1139      | A | 0.4+0.5 | 1.0     | 1.0     | 1.0     | 1.0     | 0.4     | 0.4     | 0.4     | 0.5     | 0.5     | 0.5     | 0.5     |
|                           |                      | B | 85      | 90      | 95      | 100     | 100     | 95      | 100     | 110     | 115     | 125     | 130     | 140     |
| 7                         | 0.1140 – 0.1317      | A | 0.4+0.4 | 0.4+0.5 | 0.4+0.5 | 0.4+0.5 | 0.4+0.5 | —       | 0.4     | 0.4     | 0.4     | 0.4     | 0.4     | 0.5     |
|                           |                      | B | 75      | 80      | 80      | 85      | 90      | 85      | 90      | 95      | 100     | 110     | 115     | 120     |
| 8                         | 0.1318 – 0.1495      | A | 0.4+0.4 | 0.4+0.4 | 0.4+0.4 | 0.4+0.4 | 0.4+0.5 | —       | —       | —       | 0.4     | 0.4     | 0.4     | 0.4     |
|                           |                      | B | 65      | 65      | 70      | 75      | 75      | 70      | 75      | 80      | 85      | 90      | 95      | 100     |
| 9                         | 0.1496 – 0.1673      | A | 0.5     | 0.5     | 0.5     | 0.4+0.4 | 0.4+0.4 | —       | —       | —       | —       | —       | 0.4     | 0.4     |
|                           |                      | B | 55      | 55      | 60      | 60      | 65      | 55      | 60      | 65      | 70      | 75      | 80      | 85      |
| 10                        | 0.1674 – 0.1853      | A | 0.5     | 0.5     | 0.5     | 0.5     | 0.5     | —       | —       | —       | —       | —       | —       | —       |
|                           |                      | B | 45      | 45      | 50      | 50      | 55      | 40      | 45      | 50      | 55      | 55      | 60      | 65      |
| 11                        | 0.1854 – 0.2035      | A | 0.5     | 0.5     | 0.5     | 0.5     | 0.5     | —       | —       | —       | —       | —       | —       | —       |
|                           |                      | B | 35      | 35      | 35      | 40      | 40      | 30      | 30      | 35      | 40      | 40      | 45      | 45      |
| 12                        | 0.2036 – 0.2217      | A | 0.4     | 0.4     | 0.5     | 0.5     | 0.5     | —       | —       | —       | —       | —       | —       | —       |
|                           |                      | B | 20      | 25      | 25      | 25      | 25      | 15      | 20      | 20      | 20      | 25      | 25      | 30      |
| 13                        | 0.2218 – 0.2401      | A | —       | 0.4     | 0.4     | 0.4     | 0.4     | —       | —       | —       | —       | —       | —       | —       |
|                           |                      | B | 10      | 10      | 15      | 15      | 15      | 5       | 5       | 5       | 5       | 10      | 10      | 10      |
| 14                        | 0.2402 – 0.2493      | A | —       | —       | —       | 0.4     | 0.4     | —       | —       | —       | —       | —       | —       | —       |
|                           |                      | B | 0       | 0       | 0       | 5       | 5       | 0       | 0       | 5       | 5       | 5       | 5       | 5       |

| Angle of optical axis (°) | Screen size (inches) |   | 210     | 220     | 230     | 240     | 250     | 260     | 270     | 280     | 290     | 300     |
|---------------------------|----------------------|---|---------|---------|---------|---------|---------|---------|---------|---------|---------|---------|
|                           | B'                   | E |         |         |         |         |         |         |         |         |         |         |
| 1                         | 0.0087 - 0.0262      | A | 0.4+0.4 | 0.4+0.4 | 0.4+0.4 | 0.4+0.4 | 0.4+0.4 | 0.4+0.4 | 0.4+0.4 | 0.4+0.4 | 0.4+0.5 | 0.4+0.5 |
|                           |                      | B | 175     | 180     | 190     | 200     | 205     | 215     | 225     | 235     | 240     | 250     |
| 2                         | 0.0263 - 0.0437      | A | 0.4+0.4 | 0.4+0.4 | 0.4+0.4 | 0.4+0.4 | 0.4+0.4 | 0.4+0.4 | 0.4+0.4 | 0.4+0.4 | 0.4+0.4 | 0.4+0.4 |
|                           |                      | B | 175     | 180     | 190     | 200     | 210     | 215     | 225     | 235     | 245     | 250     |
| 3                         | 0.0438 - 0.0612      | A | 0.5     | 0.5     | 0.5     | 0.5     | 0.5     | 0.4+0.4 | 0.4+0.4 | 0.4+0.4 | 0.4+0.4 | 0.4+0.4 |
|                           |                      | B | 170     | 180     | 185     | 195     | 205     | 215     | 225     | 235     | 245     | 250     |
| 4                         | 0.0613 - 0.0787      | A | 0.5     | 0.5     | 0.5     | 0.5     | 0.5     | 0.5     | 0.5     | 0.4+0.4 | 0.4+0.4 | 0.4+0.4 |
|                           |                      | B | 170     | 180     | 185     | 195     | 205     | 215     | 220     | 230     | 240     | 245     |
| 5                         | 0.0788 - 0.0963      | A | 0.5     | 0.5     | 0.5     | 0.5     | 0.5     | 0.5     | 0.5     | 0.5     | 0.5     | 0.5     |
|                           |                      | B | 165     | 170     | 180     | 190     | 195     | 205     | 215     | 220     | 230     | 235     |
| 6                         | 0.0964 - 0.1139      | A | 0.5     | 0.5     | 0.5     | 0.5     | 0.5     | 0.4     | 0.5     | 0.5     | 0.5     | 0.5     |
|                           |                      | B | 145     | 155     | 160     | 165     | 175     | 185     | 190     | 200     | 205     | 210     |
| 7                         | 0.1140 - 0.1317      | A | 0.5     | 0.5     | 0.5     | 0.5     | 0.5     | 0.4     | 0.4     | 0.4     | 0.4     | 0.4     |
|                           |                      | B | 125     | 135     | 140     | 145     | 155     | 160     | 165     | 170     | 180     | 185     |
| 8                         | 0.1318 - 0.1495      | A | 0.4     | 0.4     | 0.5     | 0.5     | 0.5     | 0.5     | 0.5     | 0.5     | 0.5     | 0.4     |
|                           |                      | B | 110     | 115     | 120     | 125     | 130     | 135     | 141     | 145     | 150     | 160     |
| 9                         | 0.1496 - 0.1673      | A | 0.4     | 0.4     | 0.4     | 0.4     | 0.5     | 0.5     | 0.5     | 0.5     | 0.5     | 0.5     |
|                           |                      | B | 90      | 95      | 100     | 105     | 110     | 115     | 115     | 120     | 125     | 130     |
| 10                        | 0.1674 - 0.1853      | A | 0.4     | 0.4     | 0.4     | 0.4     | 0.4     | 0.5     | 0.5     | 0.5     | 0.5     | 0.5     |
|                           |                      | B | 70      | 70      | 75      | 80      | 80      | 20      | 20      | 20      | 20      | 20      |
| 11                        | 0.1854 - 0.2035      | A | —       | —       | 0.4     | 0.4     | 0.4     | 0.4     | 0.4     | 0.4     | 0.5     | 0.5     |
|                           |                      | B | 50      | 50      | 55      | 55      | 60      | 10      | 10      | 15      | 15      | 15      |
| 12                        | 0.2036 - 0.2217      | A | —       | —       | —       | —       | 0.4     | 0.4     | 0.4     | 0.4     | 0.4     | 0.4     |
|                           |                      | B | 30      | 30      | 35      | 35      | 40      | 10      | 10      | 15      | 15      | 15      |
| 13                        | 0.2218 - 0.2401      | A | —       | —       | —       | —       | —       | —       | 0.4     | 0.4     | 0.4     | 0.4     |
|                           |                      | B | 10      | 15      | 15      | 15      | 15      | 10      | 10      | 15      | 15      | 15      |
| 14                        | 0.2402 - 0.2493      | A | —       | —       | —       | —       | —       | —       | —       | —       | —       | —       |
|                           |                      | B | 5       | 10      | 10      | 10      | 10      | 0       | 0       | 0       | 0       | 0       |

1-25. PROJECTION DISTANCE BY ANGLE OF OPTICAL AXIS



| Screen size (inches) | a = 1° |        | a = 2° |        | a = 3° |        | a = 4° |        | a = 5° |        | a = 6° |        |
|----------------------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|--------|
|                      | F (mm) | D (mm) |
| 70                   | 2038   | 2037   | 2038   | 2037   | 2039   | 2036   | 2039   | 2035   | 2040   | 2032   | 2041   | 2030   |
| 72                   | 2091   | 2091   | 2092   | 2090   | 2168   | 2089   | 2093   | 2088   | 2093   | 2085   | 2094   | 2083   |
| 75                   | 2170   | 2170   | 2171   | 2169   | 2171   | 2168   | 2172   | 2167   | 2173   | 2164   | 2174   | 2162   |
| 80                   | 2302   | 2302   | 2303   | 2301   | 2303   | 2300   | 2304   | 2299   | 2313   | 2304   | 2316   | 2303   |
| 85                   | 2437   | 2437   | 2435   | 2433   | 2444   | 2440   | 2454   | 2448   | 2464   | 2454   | 2467   | 2454   |
| 86                   | 2461   | 2460   | 2461   | 2460   | 2462   | 2458   | 2463   | 2457   | 2470   | 2460   | 2476   | 2462   |
| 90                   | 2566   | 2566   | 2567   | 2565   | 2568   | 2564   | 2568   | 2562   | 2569   | 2559   | 2570   | 2556   |
| 95                   | 2698   | 2698   | 2698   | 2697   | 2700   | 2696   | 2700   | 2694   | 2701   | 2690   | 2703   | 2688   |
| 100                  | 2830   | 2830   | 2831   | 2829   | 2832   | 2828   | 2832   | 2826   | 2833   | 2822   | 2835   | 2819   |
| 105                  | 2963   | 2962   | 2964   | 2962   | 2965   | 2960   | 2965   | 2958   | 2966   | 2954   | 2968   | 2952   |
| 110                  | 3096   | 3095   | 3097   | 3095   | 3098   | 3093   | 3098   | 3091   | 3099   | 3087   | 3101   | 3084   |
| 115                  | 3224   | 3223   | 3225   | 3223   | 3225   | 3221   | 3226   | 3219   | 3227   | 3214   | 3229   | 3211   |
| 120                  | 3352   | 3351   | 3352   | 3350   | 3353   | 3349   | 3354   | 3346   | 3355   | 3342   | 3357   | 3339   |
| 125                  | 3484   | 3483   | 3484   | 3482   | 3488   | 3454   | 3486   | 3478   | 3487   | 3473   | 3489   | 3470   |
| 130                  | 3616   | 3615   | 3616   | 3614   | 3617   | 3612   | 3619   | 3610   | 3629   | 3615   | 3630   | 3610   |
| 135                  | 3748   | 3747   | 3749   | 3746   | 3751   | 3744   | 3753   | 3744   | 3773   | 3758   | 3773   | 3753   |
| 139                  | 3853   | 3852   | 3854   | 3852   | 3855   | 3850   | 3868   | 3858   | 3887   | 3871   | 3888   | 3866   |
| 140                  | 3880   | 3879   | 3881   | 3878   | 3882   | 3876   | 3888   | 3879   | 3901   | 3885   | 3905   | 3883   |
| 145                  | 4012   | 4011   | 4013   | 4010   | 4014   | 4008   | 4015   | 4005   | 4022   | 4006   | 4027   | 4005   |
| 150                  | 4144   | 4143   | 4145   | 4142   | 4146   | 4140   | 4147   | 4137   | 4149   | 4132   | 4151   | 4128   |
| 155                  | 4275   | 4274   | 4276   | 4274   | 4277   | 4271   | 4279   | 4268   | 4280   | 4263   | 4283   | 4259   |
| 160                  | 4406   | 4405   | 4407   | 4405   | 4409   | 4403   | 4410   | 4399   | 4412   | 4394   | 4414   | 4390   |
| 165                  | 4538   | 4537   | 4539   | 4536   | 4540   | 4534   | 4541   | 4531   | 4543   | 4525   | 4546   | 4521   |
| 170                  | 4669   | 4668   | 4670   | 4667   | 4672   | 4665   | 4673   | 4662   | 4675   | 4656   | 4677   | 4652   |
| 175                  | 4800   | 4799   | 4802   | 4799   | 4803   | 4796   | 4804   | 4793   | 4806   | 4787   | 4809   | 4782   |
| 180                  | 4932   | 4931   | 4933   | 4930   | 4934   | 4927   | 4936   | 4924   | 4937   | 4918   | 4940   | 4913   |
| 185                  | 5063   | 5062   | 5064   | 5061   | 5066   | 5059   | 5067   | 5055   | 5069   | 5049   | 5072   | 5044   |
| 190                  | 5194   | 5193   | 5196   | 5193   | 5197   | 5190   | 5199   | 5186   | 5200   | 5180   | 5203   | 5175   |
| 195                  | 5326   | 5325   | 5327   | 5324   | 5329   | 5321   | 5330   | 5317   | 5332   | 5311   | 5335   | 5306   |
| 200                  | 5457   | 5456   | 5458   | 5455   | 5460   | 5452   | 5462   | 5448   | 5463   | 5442   | 5467   | 5437   |
| 205                  | 5590   | 5589   | 5592   | 5588   | 5593   | 5585   | 5595   | 5581   | 5597   | 5574   | 5600   | 5569   |
| 210                  | 5723   | 5722   | 5725   | 5721   | 5726   | 5718   | 5728   | 5714   | 5730   | 5707   | 5733   | 5702   |
| 215                  | 5856   | 5855   | 5858   | 5854   | 5860   | 5851   | 5861   | 5847   | 5863   | 5840   | 5867   | 5834   |
| 220                  | 5990   | 5988   | 5991   | 5988   | 5993   | 5984   | 5995   | 5980   | 5997   | 5973   | 6000   | 5967   |
| 225                  | 6123   | 6121   | 6124   | 6121   | 6126   | 6117   | 6128   | 6113   | 6130   | 6105   | 6133   | 6100   |
| 230                  | 6256   | 6255   | 6257   | 6254   | 6259   | 6251   | 6261   | 6246   | 6263   | 6238   | 6267   | 6232   |
| 235                  | 6389   | 6388   | 6391   | 6387   | 6392   | 6384   | 6394   | 6379   | 6397   | 6371   | 6400   | 6365   |
| 240                  | 6522   | 6521   | 6524   | 6520   | 6526   | 6517   | 6528   | 6512   | 6530   | 6504   | 6534   | 6498   |
| 245                  | 6655   | 6654   | 6657   | 6653   | 6659   | 6650   | 6661   | 6645   | 6663   | 6636   | 6667   | 6630   |
| 250                  | 6788   | 6787   | 6790   | 6786   | 6792   | 6783   | 6794   | 6778   | 6796   | 6769   | 6800   | 6763   |
| 260                  | 7055   | 7053   | 7057   | 7053   | 7058   | 7048   | 7061   | 7044   | 7063   | 7036   | 7067   | 7028   |
| 270                  | 7321   | 7320   | 7323   | 7319   | 7325   | 7315   | 7327   | 7309   | 7330   | 7302   | 7334   | 7293   |
| 280                  | 7587   | 7586   | 7589   | 7584   | 7591   | 7581   | 7594   | 7576   | 7596   | 7567   | 7601   | 7559   |
| 290                  | 7853   | 7852   | 7856   | 7851   | 7858   | 7847   | 7860   | 7841   | 7863   | 7833   | 7867   | 7824   |
| 300                  | —      | —      | —      | —      | —      | —      | —      | —      | 8130   | 8099   | 8134   | 8089   |

| Screen size (inches) | a = 7° |        | a = 8° |        | a = 9° |        | a = 10° |        | a = 11° |        | a = 12° |        |
|----------------------|--------|--------|--------|--------|--------|--------|---------|--------|---------|--------|---------|--------|
|                      | F (mm) | D (mm) | F (mm) | D (mm) | F (mm) | D (mm) | F (mm)  | D (mm) | F (mm)  | D (mm) | F (mm)  | D (mm) |
| 70                   | 2042   | 2027   | 2044   | 2024   | 2045   | 2020   | 2047    | 2016   | 2049    | 2012   | 2051    | 2006   |
| 72                   | 2096   | 2080   | 2097   | 2077   | 2099   | 2073   | 2101    | 2069   | 2103    | 2064   | 2105    | 2059   |
| 75                   | 2175   | 2159   | 2177   | 2155   | 2178   | 2152   | 2180    | 2147   | 2182    | 2142   | 2185    | 2137   |
| 80                   | 2317   | 2300   | 2319   | 2296   | 2319   | 2291   | 2320    | 2285   | 2322    | 2279   | 2323    | 2272   |
| 85                   | 2469   | 2451   | 2471   | 2447   | 2471   | 2441   | 2472    | 2435   | 2473    | 2428   | 2476    | 2421   |
| 86                   | 2478   | 2459   | 2479   | 2455   | 2483   | 2452   | 2488    | 2450   | 2491    | 2445   | 2492    | 2438   |
| 90                   | 2572   | 2553   | 2574   | 2549   | 2576   | 2545   | 2582    | 2542   | 2584    | 2537   | 2586    | 2529   |
| 95                   | 2704   | 2684   | 2707   | 2680   | 2709   | 2675   | 2711    | 2670   | 2714    | 2664   | 2718    | 2658   |
| 100                  | 2837   | 2815   | 2839   | 2811   | 2841   | 2806   | 2844    | 2801   | 2847    | 2795   | 2851    | 2788   |
| 105                  | 2970   | 2948   | 2972   | 2943   | 2975   | 2938   | 2978    | 2932   | 2981    | 2926   | 2984    | 2919   |
| 110                  | 3103   | 3080   | 3106   | 3075   | 3108   | 3070   | 3111    | 3064   | 3114    | 3057   | 3118    | 3050   |
| 115                  | 3231   | 3207   | 3234   | 3202   | 3236   | 3197   | 3240    | 3190   | 3243    | 3183   | 3247    | 3175   |
| 120                  | 3359   | 3334   | 3362   | 3329   | 3365   | 3323   | 3368    | 3317   | 3372    | 3309   | 3376    | 3301   |
| 125                  | 3492   | 3465   | 3494   | 3460   | 3497   | 3454   | 3501    | 3447   | 3504    | 3440   | 3509    | 3431   |
| 130                  | 3632   | 3605   | 3632   | 3597   | 3637   | 3592   | 3639    | 3584   | 3640    | 3573   | 3642    | 3561   |
| 135                  | 3776   | 3748   | 3776   | 3739   | 3779   | 3733   | 3783    | 3725   | 3785    | 3716   | 3784    | 3701   |
| 139                  | 3890   | 3861   | 3890   | 3853   | 3894   | 3846   | 3899    | 3839   | 3900    | 3828   | 3901    | 3815   |
| 140                  | 3913   | 3884   | 3915   | 3877   | 3920   | 3871   | 3921    | 3861   | 3925    | 3853   | 3929    | 3842   |
| 145                  | 4030   | 4000   | 4037   | 3998   | 4041   | 3991   | 4042    | 3981   | 4047    | 3973   | 4051    | 3961   |
| 150                  | 4154   | 4123   | 4159   | 4118   | 4162   | 4111   | 4165    | 4102   | 4170    | 4093   | 4175    | 4083   |
| 155                  | 4285   | 4253   | 4289   | 4247   | 4293   | 4240   | 4297    | 4232   | 4302    | 4223   | 4307    | 4212   |
| 160                  | 4417   | 4384   | 4421   | 4378   | 4425   | 4370   | 4429    | 4362   | 4434    | 4353   | 4440    | 4342   |
| 165                  | 4549   | 4515   | 4552   | 4508   | 4557   | 4500   | 4561    | 4492   | 4567    | 4482   | 4572    | 4472   |
| 170                  | 4680   | 4645   | 4684   | 4639   | 4688   | 4631   | 4693    | 4622   | 4699    | 4612   | 4704    | 4601   |
| 175                  | 4812   | 4776   | 4816   | 4769   | 4820   | 4761   | 4825    | 4752   | 4831    | 4742   | 4837    | 4730   |
| 180                  | 4944   | 4907   | 4948   | 4900   | 4952   | 4891   | 4957    | 4882   | 4963    | 4872   | 4969    | 4860   |
| 185                  | 5075   | 5037   | 5079   | 5030   | 5084   | 5021   | 5090    | 5012   | 5095    | 5001   | 5101    | 4989   |
| 190                  | 5207   | 5168   | 5211   | 5161   | 5216   | 5152   | 5222    | 5142   | 5227    | 5131   | 5234    | 5119   |
| 195                  | 5339   | 5299   | 5343   | 5291   | 5348   | 5282   | 5354    | 5272   | 5360    | 5261   | 5366    | 5248   |
| 200                  | 5470   | 5429   | 5475   | 5422   | 5480   | 5412   | 5486    | 5402   | 5492    | 5391   | 5498    | 5377   |
| 205                  | 5604   | 5562   | 5608   | 5554   | 5613   | 5544   | 5619    | 5534   | 5626    | 5522   | 5633    | 5509   |
| 210                  | 5737   | 5694   | 5748   | 5692   | 5747   | 5676   | 5753    | 5666   | 5760    | 5654   | 5767    | 5640   |
| 215                  | 5871   | 5827   | 5875   | 5818   | 5881   | 5808   | 5887    | 5798   | 5894    | 5785   | 5901    | 5771   |
| 220                  | 6004   | 5959   | 6009   | 5951   | 6014   | 5940   | 6021    | 5929   | 6028    | 5917   | 6035    | 5902   |
| 225                  | 6138   | 6092   | 6143   | 6083   | 6148   | 6073   | 6155    | 6061   | 6162    | 6048   | 6169    | 6033   |
| 230                  | 6271   | 6224   | 6276   | 6215   | 6282   | 6205   | 6289    | 6193   | 6296    | 6180   | 6303    | 6165   |
| 235                  | 6405   | 6357   | 6410   | 6348   | 6416   | 6337   | 6422    | 6325   | 6430    | 6311   | 6437    | 6296   |
| 240                  | 6538   | 6489   | 6543   | 6480   | 6549   | 6469   | 6556    | 6457   | 6564    | 6443   | 6572    | 6427   |
| 245                  | 6672   | 6622   | 6676   | 6612   | 6683   | 6601   | 6690    | 6588   | 6698    | 6574   | 6706    | 6558   |
| 250                  | 6805   | 6754   | 6810   | 6744   | 6817   | 6733   | 6823    | 6720   | 6832    | 6706   | 6840    | 6689   |
| 260                  | 7092   | 7033   | 7078   | 7009   | 7084   | 6997   | 7101    | 6993   | 7107    | 6976   | 7113    | 6958   |
| 270                  | 7339   | 7299   | 7345   | 7274   | 7352   | 7261   | 7369    | 7257   | 7376    | 7240   | 7382    | 7221   |
| 280                  | 7606   | 7564   | 7612   | 7538   | 7619   | 7525   | 7637    | 7521   | 7644    | 7504   | 7650    | 7483   |
| 290                  | 7873   | 7830   | 7879   | 7802   | 7886   | 7789   | 7905    | 7785   | 7912    | 7767   | 7919    | 7746   |
| 300                  | 8140   | 8095   | 8146   | 8067   | 8154   | 8054   | 8173    | 8049   | 8181    | 8031   | 8187    | 8008   |